


Nokia Wireless Plug-in Car Handsfree (HF-6W) User Guide



9239331
Issue 1 EN





DECLARATION OF CONFORMITY

We, NOKIA CORPORATION declare under our sole responsibility that the product HF-6W is in conformity with the provisions of the following Council Directive: 1999/5/EC.

A copy of the Declaration of Conformity can be found from http://www.nokia.com/phones/declaration_of_conformity/.

CE 0560




Copyright © 2005 Nokia. All rights reserved.


Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia is a registered trademark of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.







Under no circumstances shall Nokia be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.

English




The availability of particular products may vary by region. Please check with the Nokia dealer nearest to you.

Export Controls

This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

9239331/Issue 1 EN



Contents

Contents

For your safety.....	6
1. Introduction	7
2. Get started	8
Handsfree parts	8
Install the handsfree in the car.....	9
Switch the handsfree on and off.....	10
Pair the handsfree with a phone	11
Disconnect the handsfree from the phone	12
Reconnect the handsfree to the phone.....	13
3. Basic use.....	14
Call functions.....	14
Answer and end a call	14
Automatic answer	15
Reject a call.....	15
Mute or unmute an ongoing call.....	15
Switch the call between handsfree and phone	16
Multiple calls.....	16






Contents



Adjust the handsfree volume	16
Charge a compatible phone battery	16
Use the handsfree with multiple paired phones	17
Reset the handsfree	18
Troubleshooting	18
Care and maintenance	20
Additional safety information	22

English





For your safety



For your safety

Read these simple guidelines. Not following them may be dangerous or illegal. Read the complete user guide for further information.



ROAD SAFETY COMES FIRST

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.



INTERFERENCE

All wireless devices may be susceptible to interference, which could affect performance.




CONNECTING TO OTHER DEVICES

When connecting to any other device, read its user guide for detailed safety instructions. Do not connect incompatible products.



QUALIFIED SERVICE

Only qualified personnel may repair this device.



Introduction

1. Introduction

The Nokia Wireless Plug-in Car Handsfree (HF-6W) is an easy fit hands-free product, which is based on Bluetooth wireless technology and powered with a digital signal processor (DSP).

You can use the handsfree for call handling and to charge a compatible Nokia mobile phone.

Read this user guide carefully before using the handsfree. Check also <http://www.nokia-asia.com/support> or your local Nokia Web site for the latest version of this guide, additional information, downloads, and services related to your Nokia product.

English


Get started

2. Get started

Before you can start to use the handsfree, you must install the handsfree in the car, and pair a compatible phone with the handsfree.

■ Handsfree parts

- Power key (1)
- Answer/end key (2)
- Volume up key (3)
- Volume down key (4)
- Cable release key (5)
- Speaker (6)
- Microphones (7)
- Indicator lights (8)
- Charger cable (9)




Get started

■ Install the handsfree in the car

To function properly, the handsfree must be connected to the cigarette lighter socket of a car, and power must be supplied by the car battery.

Insert the handsfree into the cigarette lighter socket of your car as shown in Figure A or Figure B.

Make sure that the handsfree is properly locked in place, and does not interfere with the normal operation of the car.





English



Get started

Speech tracking works optimally when the speech sound is coming from the area indicated with light gray in the figure. If you encounter unsatisfactory performance, realign the device.




In some car models, the cigarette lighter socket is powered by the car battery even when the ignition key is removed. In those cases, the car battery might be discharged if the handsfree is left on, or if the handsfree is turned off but connected to the cigarette lighter socket for a long time. Contact the vehicle manufacturer for more information.



■ Switch the handsfree on and off

To switch on, press the power key. The handsfree beeps, and the green indicator light is displayed briefly.



Get started

To switch off, press the power key when no call is in progress. The handsfree beeps, and the red indicator light is displayed briefly.

■ Pair the handsfree with a phone

The handsfree is specially designed for compatible Nokia phones that support Bluetooth wireless technology. You can, however, use the handsfree with any compatible Bluetooth device that supports the Bluetooth Handsfree profile. Refer to the user guide of your phone for more information on Bluetooth wireless technology.

Before you can use the handsfree, you must pair it with a compatible phone.

1. Make sure that the compatible phone is switched on.
2. Make sure that the handsfree is installed properly, and press the power key to switch it on.


English




Get started



3. Set the phone to search for Bluetooth devices. See the user guide of your phone for instructions.
4. Select the handsfree (Nokia HF-6W) from the list.
5. Enter the Bluetooth passcode 0000 to pair the handsfree with the phone. The phone becomes the default phone for the handsfree, if the handsfree has not been previously paired with another phone.




The handsfree beeps shortly, and a continuous blue indicator light indicates an active Bluetooth connection.



6. Start to use the handsfree.

Disconnect the handsfree from the phone

If you want to disconnect the handsfree from your phone (for example, to connect the phone to another Bluetooth device), switch off the handsfree, or disconnect the handsfree in the Bluetooth menu of the phone.



Get started

You do not need to delete the pairing with the handsfree to disconnect it.

Reconnect the handsfree to the phone

If you want to reconnect the handsfree to the default phone or the last used phone, make sure the Bluetooth feature is activated in the phone, and switch on the handsfree. When you reconnect a paired handsfree, you are not asked for its passcode.

You can set your phone to connect with the handsfree automatically when the handsfree is switched on. To do this in Nokia phones, change your paired device settings in the Bluetooth menu.

If the handsfree does not automatically reconnect to the default or the last used phone, press and hold the answer/end key. The handsfree starts to search for the default phone, followed by the last used phone. Otherwise, make the connection in the Bluetooth menu of your phone.

English



Basic use




3. Basic use


■ Call functions

To make a call, use your phone in the normal way.

To redial the last dialed number, press the answer/end key twice.




To activate voice dialing, press the answer/end key until you hear a voice dialing tone. For more information, see the user guide of your phone. Voice dialing is only available with phones that support this feature.



Answer and end a call

When you receive a call, the green indicator light blinks, and you hear a ringing tone through the handsfree. If the incoming call alert setting in your phone is off, no ringing tone is played through the handsfree.





Basic use





To answer a call, or to end the currently active call, press the answer/end key. You can also answer or end the call using the phone.

English

Automatic answer

If the automatic answer function is activated on the phone, the phone automatically answers the incoming call after a defined time period, and forwards it to the handsfree.




Reject a call

If you do not want to answer a call, briefly press the answer/end key twice.

Mute or unmute an ongoing call

Press the power key briefly. When the call is muted, the red indicator light is shown continuously.





Basic use





Switch the call between handsfree and phone

Press the answer/end key for more than 1 second.

Multiple calls

To make multiple calls, use the keypad of the phone.

To answer a waiting call from the handsfree, first end the active call, and then answer the second call.




■ Adjust the handsfree volume

To adjust the handsfree volume, use the volume keys on the handsfree or the keypad of your phone.

■ Charge a compatible phone battery

You can charge the batteries of compatible Nokia phones while using the handsfree. Pull out the charger cable from the handsfree, and connect it to the phone. When



Basic use

the battery is fully charged, disconnect the phone from the charger cable, and press the cable release key on the handsfree to retract the cable.

■ Use the handsfree with multiple paired phones

You can pair the handsfree with up to eight compatible phones, but connect to only one phone at a time.

The phone that was first paired with the handsfree is called the default phone. The phone that was last used with the handsfree is called the last used phone.

When the handsfree is switched on, the handsfree tries to connect to the default phone within a few seconds.

If the handsfree cannot connect to the default phone, the handsfree tries to connect to the last used phone within a few seconds.

If the handsfree cannot connect to either phone, it remains discoverable for other phones.

English





Basic use



To use the handsfree with a paired phone that is not the default phone or the last used phone, make the connection in the Bluetooth menu of the phone.

■ Reset the handsfree


You can reset the handsfree to clear all settings, including pairing information. Switch off the handsfree, and then press and hold the power key and the volume up key simultaneously for 10 seconds. During resetting, the green and red indicator lights blink alternately. After the handsfree is reset, it beeps twice.



■ Troubleshooting

If you cannot connect the handsfree to the compatible phone, proceed as follows:

- Make sure that the Bluetooth feature is activated on the compatible phone.








Basic use



English

- Make sure that the handsfree is properly installed, switched on, and paired with the compatible phone. Check also that there is power supplied by the car battery.
- If you use several Bluetooth devices, make sure you ended the previous Bluetooth connection from the phone.
- Ensure that the handsfree is within 10 meters of the phone and that there are no obstructions or electronic devices between the two.
- The network capacity and parameters of your network operator may degrade the sound quality of phone calls. This may occur, for example, in traffic jams, when many people in the same area are talking on the phone at the same time.








Care and maintenance



Care and maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

- Keep the device dry. Precipitation, humidity and all types of liquids or moisture can contain minerals that will corrode electronic circuits.
- Do not use or store the device in dusty, dirty areas. Its moving parts, electronic components, and microphones can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices and warp or melt certain plastics.
- Do not store the handsfree in cold areas. When it warms up to its normal temperature, moisture can form inside, which may damage electronic circuit boards.
- Do not attempt to open the device.



Care and maintenance

- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the handsfree.
- Do not paint the device. Paint can clog the moving parts, microphones or the speaker, and prevent proper operation.

If the device is not working properly, take it to the nearest authorized service facility for service.

English



Additional safety information






Additional safety information

■ Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection systems, electronic antiskid (antilock) braking systems, electronic speed control systems, and air bag systems. For more information, check with the manufacturer or its representative of your vehicle or any equipment that has been added.

Faulty installation or service may be dangerous and may invalidate any warranty that may apply to the device. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or enhancements. For vehicles equipped with an air bag, remember that air bags inflate with great force. Do not place objects, including installed or portable wireless equipment in the area over the air bag or in








Additional safety information



the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

English





Additional safety information

