



ECO-DECLARATION FOR NOKIA Wireless Keyboard SU-8W

Product type: Messaging Enhancement

Weight: 190 g

Size: Thickness 13 mm x Width 87 mm x Length 262 mm, 187 cc (cm3)

Materials

The product does not contain¹:

- Azo colorants and pigments with carcinogenic amino compounds
- Asbestos
- Benzene
- Beryllium Oxide
- Chlorofluorocarbons CFCs/HCFs/Halons as banned in the Montreal Protocol
- Polychlorinated Biphenyls (PCB) or Polychlorinated Terphenyls (PCT)
- Short Chained Chlorinated Paraffins
- Endangered species of flora and fauna

This product complies with the China legislation "Management Methods on the Prevention and Control of Pollution caused by Electronic Information Products" commonly known as "China RoHS".



The product does not contain the following substances in accordance to the EU RoHS Directive 2002/95/EC:

- | | |
|----------------------------|---|
| • Cadmium | • Mercury |
| • Chromium VI ⁺ | • Polybrominated Biphenyls (PBB) or |
| • Lead | • Polybrominated Diphenyl Ethers (PBDE) |

¹ In levels more than 100 PPM by weight in the product

All information in this eco-declaration is based on scientific analysis and/or data provided by suppliers. There may be some variance in the information.

Further material information

Antimony trioxide, Brominated and Chlorinated flame retardants are not added in covers.

The surfaces that are intended for direct and prolonged skin contact do not release nickel (Ni) above levels specified in (94/27/EEC).

Polyvinylchloride (PVC) is not used in this product or product packaging material.



Recycling and disassembly

All mechanical plastic parts have been marked where practically possible². Plastic parts are marked in accordance with ISO 11469 and ISO 1043-1 to -4 standards.

Product has been marked according to WEEE directive requirement for recycling. Do not dispose of your product as unsorted municipal waste.

Product uses separate 2 x AAA batteries.

² Dependant on size, location and materials of the part

All information in this eco-declaration is based on scientific analysis and/or data provided by suppliers. There may be some variance in the information.

INSTRUCTIONS FOR THE USER

- Always unplug the charger from the wall socket after the phone is fully charged. This avoids unnecessary power consumption of the charger in standby and saves energy.
- Electronic devices shall not be thrown into household waste but be separated for correct recycling.
- For environmentally sound recycling, contact your local Nokia service point or check local regulations for correct disposal of household electronics.
- Batteries are collected separately for battery recycling. Do not throw used batteries into household waste.
- Please separate the packaging material according to responsible waste disposal options and sorting for recycling.
- See the **Recycling Map** on <http://www.nokia.com/environment> to find the nearest collection point for used mobile phones and accessories.