

Nokia Drive User Guide

Contents

About Nokia Drive 3

Drive to your destination 3

Get voice guidance 4

Download or remove Drive maps 4

Change the look of the Drive view 4

About Nokia Drive

Select  > **Nokia Drive**.

Nokia Drive guides you where you want to go with voice-guided turn-by-turn directions.

Nokia Drive offers you:



- Voice-guided navigation
- Real-time tracking of your location, speed, and distance driven, even if not navigating
- An easy-to-use interface, optimised for in-car use
- A built-in Map Loader, so you can save on data costs by preloading maps before travelling
- A handy search feature, which offers suggestions and shows search results on the map

Drive to your destination

When you need clear turn-by-turn directions optimised for use while driving, Drive helps you get to your destination.

Select  > **Nokia Drive**.

When you open Drive for the first time, your phone asks you if you want to download street maps for your current location and a navigation voice that matches your phone language settings.

- 1 Select  > **Set destination**, and search for your destination.
- 2 Select your destination and **DRIVE TO > START**.
- 3 To stop the navigation, select  > **Stop navigation**.

You can also start driving without a set destination. The map follows your location.

By default, the map rotates to your driving direction. The compass always points north.


Tip: To view the map in full screen mode, tap the map.

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.

Get voice guidance

Voice guidance, if available for your language, helps you find your way to a destination, leaving you free to enjoy the journey.

Select  > **Nokia Drive**.

- 1 Select  > **Settings** > **Navigation voice**.
- 2 Select a language, or to not use voice guidance, select **None**.



You can also download new navigation voices.

Download navigation voices



Select  > **Settings** > **Navigation voice** > **Download new** and a voice.

Download or remove Drive maps


To save on data costs when travelling, save new street maps to your phone before your journey. If you're running low on space in your phone, you can remove some maps.

Select  > **Nokia Drive** and  > **Settings** > **Manage maps**.

Download a map

- 1 Select .
- 2 Select a continent, a country, and an area if applicable, and select **Install**.
To cancel the download, select .

Remove a map

Select the map, and on the map details page, select .

Remove all maps

Select **•••** > **All maps will be removed from your phone** > **OK**.


Using services or downloading content may cause transfer of large amounts of data, which may result in data traffic costs.

Change the look of the Drive view

Would you like to see a more realistic 3D map, or are you using **Drive** at night, when it's dark? With the different map modes, you can see the information you need clearly at all times.

Select  > **Nokia Drive**.

Change the map type

Select  > **2D** or **3D**.


To see the map clearly also when it is dark, you can use night mode.

Switch night mode on

Select  > **Settings** > **Map colours**.

To get a bigger and better view of your surroundings on the map, use the full screen map.

View the map in full screen mode

Tap the map. To display the information area, press .

Tip: By default, Drive shows prominent buildings and attractions on the map. If you don't want to see them, select  > **Settings**, and switch **Landmarks** to **OFF** .