SUPPORT GUIDE FOR
NOKIA MODEM OPTIONS
for the Nokia 7210

NOKIA

Contents

1. INTRODUCTION

First you must have the Nokia 7210 modem drivers installed on your computer and secondly if you wish to use High Speed Data or GPRS services you must have those services activated on your SIM card. Please also check from your GSM operator what speeds they support in their network and also if the High Speed Data is in use in that area whereas you are located. Then you also should ask from your ISP which connection methods they support and if they support ISDN v.110 is their modem pool capable of accepting as "low" speed, especially during login process, as your phone will give you.

When you are roaming in other GSM operator's network please verify that they have also GPRS roaming agreement

For further information please see Support Guide for Nokia Modem Options and Dial-Up for the Nokia 7210.

2. SYSTEM REQUIREMENTS

To install and run the Nokia Modem Options, you need:

- An Intel-compatible PC equipped with Windows 98/98SE/Me/2000/XP

- For connection between the Nokia 7210 and a PC you need a compatible infrared or USB port in your computer

Note: In this guide, all references to personal computers (PC) are also applicable to laptop computers.

1. Start Nokia Modem Options from *My Computer – Control Panel – Nokia Modem Options.*

2. Now you should get the Nokia Modem Options user interface on your desktop (Figure 1.).

Figure 1. Nokia Modem Options

3. Select appropriate modem from the Installed Nokia modems list (shows only High Speed Data and GPRS compatible phones)

4. Select the desired Connection method and connection speed or if you wish to use GPRS then give the access point name (APN) which you can get from your GSM service provider and click *Apply*.

5. The selected speed will be used the next time you use Dial-Up networking with your phone.

NOTE! You can reset the user interface by clicking Refresh button.