

## PC Suite for Nokia 6250

### Quick Guide

---

This guide describes briefly how to install and start using PC Suite for Nokia 6250. For more detailed information on the use of PC Suite, please refer to the online Helps of the PC Suite applications.

PC Suite for Nokia 6250 consists of four applications:

- **Nokia PC Sync** allows you to synchronize contacts and calendar items between your phone and your PC Personal Information Manager
- **Nokia PC Graphics** lets you to draw and edit caller group graphics and picture messages
- **Nokia PC Composer** allows you to create new ringing tones to your phone
- **Nokia PC Task Journal** allows you to save Task Journal data to a file, or export it to Microsoft Excel.

### System requirements

To install and run PC Suite, you need:

- An Intel compatible PC running Windows 95/98, Windows 2000, or Windows NT 4.0 with Service Pack 3 or newer
- The DLR-3P connection cable (available as an accessory) or a PC with infrared capabilities  
Note: The infrared connection is available for Windows 95/98 and Windows 2000 only.
- At least 15 MB of free disk space

### Installing PC Suite


1. Once you have downloaded the installation file (PCSuite.exe), go to the directory where you downloaded the file and double-click it.
2. Follow the instructions on the screen, and note:
  - In the **Select Components** window, the Setup program prompts you to select the applications you want to install: you can install all four applications, or the ones you want.
  - In the **Language Selection** window, select the language for PC Suite. You can select only one language, and this language will be used in all the installed PC Suite applications.
  - In the **Connection Method Selection** window, select the connection method: you can select a cable connection, an infrared connection (available for Windows 95/98/2000), or both. After selecting the connection method(s), the Setup program

prompts you to connect your phone to the PC by using the selected connection method(s).

## Getting started

### Starting a PC Suite application

You can start PC Suite applications from the Start menu: click the **Start** button, point to **Programs** and **PC Suite for Nokia 6250**, and then click the application you want.

When Nokia PC Sync is running, the Nokia PC Sync icon  appears on the taskbar. You can access the Nokia PC Sync menu commands by right-clicking this icon.

**Tip:** You can set Nokia PC Sync to start automatically on startup. To do this, right-click the Nokia PC Sync icon on the taskbar and select **Enable on Startup**.

### Creating a new synchronization task

To create a new synchronization task, click the **Start** button, point to **Programs** and **PC Suite for Nokia 6250**, and then click **New Synchronization**.

**Note:** You cannot make data or fax calls with your phone while any of the Nokia PC Suite applications is active. Also, you cannot use Nokia PC Suite applications while you are having active data or fax calls.

### Connecting your phone to the PC

To be able to synchronize calendar items and contacts between your phone and PC application, and to transfer group graphics, picture messages and ringing tones between your phone and PC, you must connect the phone to the PC. You can use an infrared connection (available for Windows 95/98/2000) or a cable connection (the DLR-3P cable is available as an accessory). If you selected both connection methods in the Setup program, you can choose which one to use. The selection is made in the PC Suite application. For more information, see the online Helps of the PC Suite applications.

### Changing the language

The language selection is made in the Setup program. You can select only one language, and this language will be used in all the installed PC Suite applications. To change the language, you need to reinstall PC Suite.

### Uninstalling PC Suite

1. Click the **Start** button, point to **Settings** and click **Control Panel**.
2. Double-click **Add/Remove Programs**.
3. In the Install/Uninstall tab, select **PC Suite for Nokia 6250** from the list of software that can be removed.
4. Click **Add/Remove**.
5. In the Nokia PC Suite Setup view, click **Remove** and then click **Next**.
6. Follow the instructions on the screen until the program files are removed.

**Important safety notes**

All the safety instructions in the user's guides of your phone and computer also apply when this product is used with the phone.

Remember to make backup copies of all important data to protect against possible loss or alteration.

Do not point the infrared beam at anyone's eyes or allow it to interfere with other infrared devices.

To disconnect the cable from the phone, hold the connector and remove the cable.