NOKIA 7610

MMS, WAP & INTERNET SETTINGS

A GUIDE TO USING THE SETTING WIZARD

NOKIA

Contents

1.   INTRODUCTION

The Setting Wizard application configures your phone's settings that enable you to use the browsers and to send and receive Multimedia Messages and emails.

The purpose of this document is to help you to use the Setting Wizard application on your Nokia 7610 phone.

2.   INSTALLING THE SETTING WIZARD

The Setting Wizard can be downloaded from http://www.nokia.com/phonesettings. Select your phone model and save the downloaded file to your computer. Transfer the file to your Nokia 7610 using one of the methods below. The application can be installed in either Phone Memory or MMC.

1. Transfer the application to your phone using PC Suite's Application Installer. The application will then install automatically.

2. Alternatively, send the file direct to your Nokia 7610's Inbox via Bluetooth.

Install the application by selecting Install from the Inbox menu.

Once installed, the application can be found and run from the main menu, see below.

For further information on how to make a connection to a compatible computer via USB or Bluetooth, or how to install Nokia PC Suite, see the User's Guide for Nokia PC Suite on the CD-ROM. For further information on how to use Nokia PC Suite, see the help function on PC Suite or visit the support pages at http://www.nokia.com/

3. RUNNING THE SETTING WIZARD

1. Because the Setting Wizard configures settings for WAP, MMS and Internet access, the application should be run before manually configuring any other browser or messaging settings.

2. Ensure that all other applications are closed.

3. The Setting Wizard application can be found in the applications list. Press the **Applications** button and scroll down until you highlight the Setting Wizard icon.

4. Press the **Joystick** button or select **Options** > **Open** to run the application. When you run the application for the first time, you will be asked to accept the Disclaimer in the End User Licence Agreement.

5. After accepting the Disclaimer, the Setting Wizard will display the instruction screen:

Press **OK** to continue or **Exit** to return to the phone's application menu.

6. The Setting Wizard automatically detects your network operator by reading the details from your SIM card.

    a. If the Setting Wizard does not recognise your SIM card, you will be asked to select your country and network operator from a list.

    b. Select **Options** > **Change** to access the country list. You can also use the **Joystick** to highlight the Country and press the **Joystick** to change and then select the correct country.

c. Once the country is selected, you may then choose the network operator.

Scroll down to highlight the Operator. Select **Options** > **Change** to access the network operator list. You can also use the **Joystick** to change and then select the correct network operator.

d. Once the country and operator have been chosen, select **Options** > **OK**

e. Although the Setting Wizard has a list of more than 200 network operators, if your country and network operator cannot be found from the list, please close the Setting Wizard application and visit http://www.nokia.com/phonesettings to have your network operator settings sent via text message to your phone.

5/8

7. The Setting Wizard will then confirm that you want to create the settings for your chosen network operator. Select **OK** to proceed or **Cancel** to return to the country and network operator lists.

8. The Setting Wizard will then program your phone. Progress bars will be visible for approximately 5-10 seconds.

9. Congratulations! Your phone is now configured for MMS, WAP and Internet access.

Notes: Please note that to use these services, you may have to contact your network operator or service provider to activate GPRS. Where possible, the Setting Wizard will display the telephone number to call.

Please note that not all network operators support all services.

Select **OK** to close the Setting Wizard and return to the phone's application menu.

4. ABOUT THE SETTING WIZARD

1. The Nokia 7610 Setting Wizard is a Symbian 7.0 application developed for Nokia by a third party.

2. Because the Setting Wizard configures GPRS and other settings for WAP, MMS and Internet access, the application should be run before manually configuring any other browser or messaging settings.

3. Email configuration settings can be sent directly to your phone via Nokia's Phone Settings web site at http://www.nokia.com/phonesettings

4. Should you experience any problems with the Setting Wizard, please visit Nokia's Phone Settings web site at http://www.nokia.com/phonesettings to download the latest version of Setting Wizard or to have your network operator's latest settings sent directly to your phone via text message.