



NOKIA 7610

User's Guide

9311985

Issue 1 EN

CE 168

DECLARATION OF CONFORMITY

We, NOKIA CORPORATION declare under our sole responsibility that the product RH-51 is in conformity with the provisions of the following Council Directive: 1999/5/EC. A copy of the Declaration of Conformity can be found at http://www.nokia.com/phones/declaration_of_conformity/

Copyright © 2004 Nokia. All rights reserved.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia, Nokia Connecting People and Xpress-on are registered trademarks of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Nokia tune is a sound mark of Nokia Corporation.

symbian

This product includes software licensed from Symbian Ltd © 1998-2004. Symbian and Symbian OS are trademarks of Symbian Ltd.



Java™ and all Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc.

Stac ©, LZS ©, ©1996, Stac, Inc., ©1994-1996 Microsoft Corporation. Includes one or more U.S. Patents: No. 4701745, 5016009, 5126739, 5146221, and 5414425. Other patents pending.

Hi/fn ©, LZS ©, ©1988-98, Hi/fn. Includes one or more U.S. Patents: No. 4701745, 5016009, 5126739, 5146221, and 5414425. Other patents pending.

Part of the software in this product is © Copyright ANT Ltd. 1998. All rights reserved.

m-Router Connectivity Components © 2000-2002 Intuwave Limited. All rights reserved. (www.intuwave.com)

US Patent No 5818437 and other pending patents. T9 text input software Copyright (C) 1997-2004. Tegic Communications, Inc. All rights reserved.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Under no circumstances shall Nokia be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided 'as is'. Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice

The availability of particular products may vary by region. Please check with the Nokia dealer nearest to you.

9311985
Issue 1 EN

Copyright © 2004 Nokia. All rights reserved.

Contents

For your safety	7
General information	10
Putting on the wrist strap.....	10
Essential indicators in standby mode	10
Menu	11
Switching between applications	12
Actions common to all applications	12
Volume control.....	13
Shared memory	14
Your phone	15
Making a call	15
Making a call using the Contacts directory	15
Calling your voice mailbox (Network Service).....	16
Speed dialling a phone number	16
Making a conference call (Network Service)	16
Answering a call	17
Options during a call	17
Call waiting (Network Service)	18
Diverting calls (Network Service).....	18
Log - Call register and general log	19
GPRS data counter	19
Recent calls register.....	19
Call duration.....	20
Viewing the general log.....	21
Personal information	22
Contacts.....	22
Creating and editing contact cards.....	22
Copying contacts between the SIM card and phone memory.....	23
Adding a ringing tone for a contact card or group 23	
Voice dialling	23
Assigning speed dialling keys.....	25
Viewing subscribed contacts.....	25
Managing contact groups.....	25
Presence (Network Service).....	26
Changing your availability information	26
Changing who can view your Presence information 26	
Updating your Presence information	29
Presence settings.....	29
Positioning (Network Service)	30
Calendar	30
Creating calendar entries.....	30
To-do.....	32
Importing data from compatible Nokia phones	32

Multimedia	33	Receiving smart messages.....	51
Camera.....	33	Receiving service messages (Network Service)	52
Taking pictures.....	33	My folders	53
Recording videos	35	Remote mailbox (Network Service)	53
Viewing images.....	36	Opening the mailbox.....	53
Zooming on a saved image.....	36	Retrieving e-mail messages from the mailbox	53
Keyboard shortcuts.....	37	Deleting e-mail messages.....	54
RealOne Player™.....	37	Disconnecting from mailbox.....	55
Playing media files.....	38	Outbox.....	55
Changing the settings.....	39	Viewing messages on a SIM card.....	56
Movie director.....	39	Cell broadcast (Network Service)	56
Gallery.....	40	Service command editor	57
Opening files.....	41	Messaging settings.....	57
Other default folders.....	41	Settings for text messages	57
Downloading files	42	Settings for multimedia messages	58
Uploading images to an image server (Network		Settings for e-mail.....	59
Service).....	42	Settings for service messages.....	61
Messaging	44	Settings for Cell broadcast (Network Service)	61
Writing text.....	45	Settings for the Other folder.....	61
Using traditional text input	45	Tools	63
Using predictive text input.....	46	Settings.....	63
Copying text to the clipboard.....	48	Changing general settings.....	63
Writing and sending messages	49	Phone settings.....	63
Settings needed for multimedia messaging	50	Call settings	65
Settings needed for e-mail.....	50	Connection settings.....	66
Inbox - receiving messages.....	50	Date and time.....	69
Viewing multimedia objects.....	51	Call barring (Network Service)	70

Network.....	70	Creating a wallet profile.....	86
Enhancement settings.....	71	Retrieving information from the wallet to your browser.....	87
Security.....	71	Viewing ticket details.....	87
Phone and SIM	71	Wallet settings.....	87
Certif. management	73	Resetting the wallet and wallet code.....	88
Device manager.....	74	Calculator	88
File manager	75	Converter.....	88
Viewing memory consumption	76	Converting units	89
Voice commands.....	76	Setting a base currency and exchange rates....	89
Adding a voice command to an application	77	Notes.....	90
Starting an application using a voice command	78	Clock	90
Replaying, erasing, or changing a voice command	78	Changing clock settings	90
		Setting an alarm	90
Personalising your phone	79	Recorder.....	91
Profiles.....	79	Games.....	91
Changing the profile.....	79	Chat (Network Service).....	92
Customising profiles	79	Before using Chat.....	92
Themes.....	80	Connecting to a chat server	92
Editing themes.....	81	Modifying your chat settings.....	93
Go to.....	82	Joining and leaving a chat group	93
Adding shortcuts.....	82	Searching for chat groups and users	94
Extras	84	Chatting in a chat group.....	94
Wallet	84	Starting and viewing individual conversations	95
Entering the wallet code	84	Chat contacts	96
Storing personal card details.....	85	Editing chat group settings.....	97
Creating personal notes.....	86	Chat and Presence servers	98
		Memory card	98

Format memory card.....	100
Backing up and restoring information.....	100
Locking the memory card.....	101
Checking memory consumption.....	101
Services and Applications.....	102
Web (Mobile browser).....	102
Basic steps for accessing.....	102
Setting up the phone for the browser service.....	103
Making a connection.....	103
Viewing bookmarks.....	104
Browsing.....	104
Downloading.....	106
Ending a connection.....	107
Browser settings.....	107
Application manager.....	108
Installing applications - general information.....	109
Removing an application.....	111
Connectivity.....	112
Bluetooth connection.....	112
Bluetooth settings.....	113
Sending data via Bluetooth.....	113
Paired devices view.....	115
Receiving data via Bluetooth.....	115
Disconnecting Bluetooth.....	116
Connection manager.....	116
Viewing connection details.....	116
Ending connections.....	117
Connecting your phone to a compatible computer.....	117
Sync - remote synchronisation.....	117
Creating a new synchronisation profile.....	118
Synchronising data.....	119
Troubleshooting.....	120
Q&A.....	121
Battery information.....	123
Care and Maintenance.....	124
Additional safety information.....	125
Index.....	128

For your safety

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this manual.



SWITCH ON SAFELY Do not switch the phone on when wireless phone use is prohibited or when it may cause interference or danger.



ROAD SAFETY COMES FIRST Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.



INTERFERENCE All wireless phones may be subject to interference, which could affect performance.



SWITCH OFF IN HOSPITALS Follow any restrictions. Switch the phone off near medical equipment.



SWITCH OFF IN AIRCRAFT Follow any restrictions. Wireless devices can cause interference in aircraft.



SWITCH OFF WHEN REFUELLING Don't use the phone at a refuelling point. Don't use near fuel or chemicals.



SWITCH OFF NEAR BLASTING Follow any restrictions. Don't use the phone where blasting is in progress.



USE SENSIBLY Use only in the normal position as explained in the product documentation. Don't touch the antenna unnecessarily.



QUALIFIED SERVICE Only qualified personnel may install or repair this product.



ENHANCEMENTS AND BATTERIES Use only approved enhancements and batteries. Do not connect incompatible products.



WATER-RESISTANCE Your phone is not water-resistant. Keep it dry.



BACKUP COPIES Remember to make backup copies or keep a written record of all important information stored in your phone.



CONNECTING TO OTHER DEVICES When connecting to any other device, read its user guide for detailed safety instructions. Do not connect incompatible products.



EMERGENCY CALLS Ensure the phone is switched on and in service. Press  as many times as needed to clear the display and return to the start screen. Key in the emergency number, then press . Give your location. Do not end the call until given permission to do so.

About your device

The wireless device described in this guide is approved for use on the EGSM 900 and GSM1800 and 1900 networks. Contact your service provider for more information about networks.

When using the features in this device, obey all laws and respect privacy and legitimate rights of others.



Warning: To use any features in this device, other than the alarm clock, the device must be switched on. Do not switch the device on when wireless device use may cause interference or danger.

Network Services

To use the phone you must have service from a wireless service provider. Many of the features in this device depend on features in the wireless network to function. These Network Services may not be available on all networks or you may have to make specific arrangements

with your service provider before you can utilize Network Services. Your service provider may need to give you additional instructions for their use and explain what charges will apply. Some networks may have limitations that affect how you can use Network Services. For instance, some networks may not support all language-dependent characters and services.

Your service provider may have requested that certain features be disabled or not activated in your device. If so, they will not appear on your device menu. Contact your service provider for more information.

This device supports WAP 2.0 protocols (HTTP and SSL) that run on TCP/IP protocols. Some features of this device, such as MMS, browsing, e-mail, remote SyncML, and content downloading via browser or over MMS, require network support for these technologies.

Chargers and enhancements



Note: Check the model number of any charger before use with this device. This device is intended for use when supplied with power from ACP-8, ACP-12, LCH-9 and LCH-12.



WARNING! Use only batteries, chargers, and enhancements approved by Nokia for use with this particular model. The use of any other types may invalidate any approval or warranty, and may be dangerous.

For availability of approved enhancements, please check with your dealer. When you disconnect the power cord of any enhancement, grasp and pull the plug, not the cord.

Your device and its enhancements may contain small parts. Keep them out of reach of small children.

General information



Warning: To use any features in this device, other than the alarm clock, the device must be switched on. Do not switch the device on when wireless device use may cause interference or danger.

Your Nokia 7610 provides various functions that are ideal for daily use, such as Camera, Video recorder, Messaging, E-mail, Wallet, Clock, Calculator, and Calendar.

Stickers in the sales package

- The stickers included on the warranty card, in the sales package, contain important information for service and customer support purposes. The sales package also includes instructions on how you should use these stickers.

Putting on the wrist strap

Thread the strap and then tighten it. See Fig. 1, p. 10.



Note: Only connect the strap to one fixture at a time. Use only Nokia approved enhancements.



Fig. 1 Putting on the wrist strap.

Essential indicators in standby mode



- You have received one or several messages to the Inbox in Messaging.



- You have received one or several voice messages. [See "Calling your voice mailbox \(Network Service\)" on page 16.](#)



- There are messages waiting to be sent in Outbox.

 - *Ringing type* has been set to *Silent*, *Message alert tone* to *Off*, and *Chat alert tone* to *On* in the currently active profile.

 - The phone's keypad is locked. See the Getting Started guide.

 - You have an active alarm.

2 - You can make calls using phone line 2 only (Network Service). [See "Line in use \(Network Service\)" on page 66.](#)

 - All calls to the phone are diverted.  - Indicates that all calls to the phone are diverted to a voice mailbox. [See "Diverting calls \(Network Service\)" on page 18.](#) If you have two phone lines, the divert indicator for the first line is **1** and for the second line **2**.

 - A data call is active.

 - Shown instead of the antenna symbol  (shown in the top left corner in standby mode) when there is an active GPRS connection.  - Shown when the GPRS connection is put on hold during voice calls.

 - Bluetooth is active. When data is transmitted via Bluetooth,  is shown.



Menu

Press  (Menu key) to display the main Menu. In the Menu, you can access all the applications in your phone.

Moving in the Menu

- Press the scroll key on the top , bottom , left  and right  (shown with blue arrows 1 to 4) to navigate the Menu.

Opening applications or folders

- Scroll to an application or a folder and press the centre of the scroll key  (shown with blue arrow 5) to open it.

 Options in the Menu: *Open*, *List view / Grid view*, *Move*, *Move to folder*, *New folder*, *App. downloads*, *Memory details*, *Help* and *Exit*.




Fig. 2 Using the scroll key.



Fig. 3 Switching between applications.

Closing applications

- Backstep by pressing **Back** or **Exit** as many times as needed to return to standby mode or select **Options**→ **Exit**.

Switching between applications

If you have several applications open and want to switch from one application to another, press and hold  (Menu key). The application switching window opens showing a list of applications that are currently open. Scroll to an application and press  to go to it.

Actions common to all applications

- **Opening items for viewing** - When you are viewing a list of files or folders, to open an item, scroll to an item and press , or select **Options**→ **Open**.
- **Editing items** - To open an item for editing, you sometimes need to first open it for viewing and then select **Options**→ **Edit**, if you want to change its contents. Use the scroll key to scroll through all fields of the item.
- **Renaming items** - To give a new name to a file or folder, scroll to it and select **Options**→ **Rename**.
- **Removing, deleting items** - Scroll to the item and select **Options**→ **Delete** or press . To delete many items at a time, you first need to mark them. See the next paragraph: 'Marking an item'.
- **Marking an item** - There are several ways to select items when you are in a list.
 - To select one item at a time, scroll to it and select **Options**→ **Mark/Unmark**→ **Mark** or press  and  at the same time. A check mark is placed next to the item.
 - To select all items in the list, select **Options**→ **Mark/Unmark**→ **Mark all**.
 - **Marking multiple items** - Press and hold , then move the scroll key down or up. As the selection moves, a check mark is placed next to the items. To end the selection, stop the scrolling with the scroll key and then release .

- After you have selected all the items you want, you can move or delete them by selecting **Options**→ *Move to folder* or *Delete*.
- To unmark an item, scroll to it and select **Options**→ *Mark/Unmark*→ *Unmark* or press  and  at the same time.
 - **Creating folders** - To create a new folder, select **Options**→ *New folder*. You are asked to give a name to the folder (max. 35 letters).
 - **Moving items to a folder** - To move items to a folder or between folders, select **Options**→ *Move to folder* (not shown if there are no folders available). When you select *Move to folder*, a list of available folders opens and you can also see the root level of the application (for moving an item out of a folder). Select the location you want the item to be moved to and press **OK**.
 - **Sending items** - To send items, to compatible devices, scroll to the item that you want to send, select **Options**→ *Send*. Select the method, the choices are *Via multimedia*, *Via Bluetooth*, and *Via e-mail*.
 - If you choose to send the item in an e-mail or a multimedia message, an editor opens. Press  to select the recipient(s) from the Contacts directory or write the phone number or e-mail address of the recipient in the *To:* field. Add text or sound and select **Options**→ *Send*. [See "Writing and sending messages" on page 49.](#)
 - Via Bluetooth. [See "Sending data via Bluetooth" on page 113.](#)

Copyright protections may prevent some images, ringing tones, and other content from being copied, modified, transferred or forwarded.

Volume control

When you have an active call or are listening to a sound, press  or  to increase or decrease the volume level, respectively.

The loudspeaker allows you to speak and listen to the phone from a short distance without having to hold the phone to your ear, for example, having it on a table nearby. The loudspeaker can be used during a call, with sound and video applications, and when

Voice volume icons:

-  - for earpiece mode,
-  - for loudspeaker mode.




Fig. 4 Volume indicators for earpiece and loudspeaker modes are shown in the navigation bar.

viewing multimedia messages. Sound and video applications use the loudspeaker by default. Using the loudspeaker makes it easier to use other applications while in a call.

To start using the loudspeaker during an already active call, select **Options**→ **Activate loudsp.** A tone is played,  is shown in the navigation bar, and the volume indicator changes.

The loudspeaker cannot be activated when you have connected a headset to the phone.



Warning: Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.

To turn off the loudspeaker when you have an active call, select **Options**→ **Activate handset.**

Shared memory

The following features in this device may share memory: contacts, text messages, and multimedia messages, images and ringing tones, Video recorder, RealOne Player™, calendar and to-do notes, and downloaded applications. Use of one or more of these features may reduce the memory available for the remaining features sharing memory. For example, saving many multimedia messages may use all of the available memory. Your device may display a message that the memory is full when you try to use a shared memory feature. In this case, delete some of the information or entries stored in the shared memory features before continuing. Some of the features, such as calendar and to-do notes may have a certain amount of memory specially allotted to them in addition to the memory shared with other features.

Your phone

Making a call

- 1 In standby mode, key in the phone number, including the area code. Press  or  to move the cursor. Press  to remove a number.
 - For international calls, press  twice for the international prefix (the + character replaces the international access code) and then key in the country code, the area code without 0, and the phone number.
- 2 Press  to call the number.
- 3 Press  to end the call (or to cancel the call attempt).

Pressing  will always end a call, even if another application is active and displayed.

When the keypad lock is on, calls still may be possible to the official emergency number programmed into your device. Key in the emergency number and press .

You can make a call using your voice so that you do not need to look at the display to key in the number. [See "Voice dialling" on page 23.](#)

Making a call using the Contacts directory

- 1 To open the Contacts directory, go to [Menu](#) → [Contacts](#).
- 2 To find a contact, scroll to the desired name, or key in the first letters of the name. The Search field opens automatically and matching contacts are listed.
- 3 Press  to start the call.
If the contact has more than one phone number, scroll to the number and press  to start the call.



Fig. 5 Making a call.

Calling your voice mailbox (Network Service)

The voice mailbox is an answering service where callers who are unable to reach you can leave you voice messages.

- To call your voice mailbox, press  and  in standby mode.
- If the phone asks for the voice mailbox number, key it in and press **OK**. You can obtain this number from your service provider.

[See "Diverting calls \(Network Service\)" on page 18.](#)

Each phone line may have its own voice mailbox number. [See "Line in use \(Network Service\)" on page 66.](#)

Changing the voice mailbox number

To change the phone number of your voice mailbox, go to **Menu**→**Tools**→**Voice mailbox** and select **Options**→**Change number**. Key in the number (obtained from your service provider) and press **OK**.

Speed dialling a phone number

↔ To view the speed dialling grid, go to **Menu**→**Tools**→**Speed dial**.

- 1 Assign a phone number to one of the speed dialling keys ( - ). [See "Assigning speed dialling keys" on page 25.](#)
- 2 To call the number: In standby mode, press the corresponding speed dialling key and . If the *Speed dialling* function is set to *On*: Press and hold the corresponding speed dialling key until the call is started.

Making a conference call (Network Service)

Your Nokia 7610 supports conference calling with up to six participants. See Fig. 6, p. 17.

- 1 Make a call to the first participant.
- 2 To make a call to a new participant, select **Options**→ **New call**. Key in or search the memory for the phone number of the participant and press **OK**. The first call is automatically put on hold.
- 3 When the new call has been answered, join the first participant in the conference call. Select **Options**→ **Conference**.
- 4 To add a new person to the call, repeat step 2 and then select **Options**→ **Conference**→ **Add to conference**.
 - To have a private conversation with one of the participants: Select **Options**→ **Conference**→ **Private**. Scroll to the desired participant and press **Private**. The conference call is put on hold in your phone, and the other participants can still continue talking with each other while you have a private discussion with one participant only. Once you have finished the private conversation, press **Cancel** to return to the conference call.
 - To drop one participant from the conference call, select **Options**→ **Conference**→ **Drop participant**, then scroll to the participant and press **Drop**.
- 5 To end the active conference call, press .



Fig. 6 Conference call with two participants.

Answering a call

- To answer an incoming call, press .
- To end the call, press .

If you do not want to answer a call, press . The caller will hear a 'line busy' tone.

When a call comes in, press **Silence** to quickly mute the ringing tone.

Options during a call

Press **Options** during a call for some of the following options:



Fig. 7 Options during a call.

Mute or Unmute, End active call, End all calls, Hold or Unhold, New call, Conference, Private, Drop participant, Answer, and Reject.

Swap is used to switch between the active call and the call on hold.

Transfer is used to connect an incoming call or a call on hold with an active call and to disconnect yourself from both calls.

Send DTMF is used to send DTMF tone sequences, for example, passwords or bank account numbers.

You may not have all of these options. Contact your service provider for more details.

- 1 Key in the digits with - . Each keystroke generates a DTMF tone, which is transmitted while the call is active. Press repeatedly to produce: *, p (inserts a pause of approximately two seconds before, or between DTMF characters.), and w (if you use this character, the remaining sequence is not sent until you press [Send](#) again during the call). Press to produce #.
- 2 To send the tone, press [OK](#).

Call waiting (Network Service)

If you have activated the Call waiting service, the network will notify you of a new incoming call while you have a call in progress.

- 1 During a call, press to answer the waiting call. The first call is put on hold. To switch between the two calls, press [Swap](#).
- 2 To end the active call, press .

Diverting calls (Network Service)

When this network service is activated, you can direct your incoming calls to another number, for example, to your voice mailbox number. For details, contact your service provider.

[Go to Menu](#) → [Settings](#) → [Call divert.](#)

- Select one of the divert options, for example, select *If busy* to divert voice calls when your number is busy or when you reject incoming calls.
- Select **Options**→ *Activate* to set the divert setting on, *Cancel* to set the divert setting off, or *Check status* to check whether the divert is activated or not.
- To cancel all active divers, select **Options**→ *Cancel all divers*.

[See "Essential indicators in standby mode" on page 10.](#)

You cannot have barring of incoming calls and call diverting active at the same time. [See "Call barring \(Network Service\)" on page 70.](#)



Log – Call register and general log

In the log you can monitor phone calls, text messages, packet data connections, and data calls registered by the phone. You can filter the log to view just one type of event and create new contact cards based on the log information.

Connections to your remote mailbox, multimedia messaging centre, or browser pages are shown as data calls or packet data connections in the general communications log.

➡ Go to **Menu**→ **Log**.

GPRS data counter

The GPRS data counter allows you to check the amount of data sent and received during packet data (GPRS) connections. This can be beneficial as you may be charged for your GPRS connections by the amount of data sent and received.

➡ Go to **Menu**→ **Log**→ **GPRS counter**.

Recent calls register

The phone registers the phone numbers of missed, received, and dialled calls, and the approximate duration of your calls. The phone registers missed and received calls only if the network supports these functions, and the phone is switched on and is within the network's service area.

➡ Go to **Menu**→ **Log**→ **Recent calls**.

Options in the Missed, Received, Dialed views: [Call](#), [Create message](#), [Use number](#), [Request presence](#), [Delete](#), [Clear list](#), [Add to Contacts](#), [Help](#), and [Exit](#).




Fig. 8 The Dialed numbers view.

Go to [Menu](#)→[Log](#)→[Call duration](#).

Missed calls and received calls

To view a list of the last 20 phone numbers from which somebody has tried to call you without success (Network Service), go to [Log](#)→[Recent calls](#)→[Missed calls](#).



Tip! When you see a note in standby mode about missed calls, press [Show](#) to access the list of missed calls. To call back, scroll to the number or name you want and press .

To view a list of the 20 numbers or names from which you have most recently accepted calls (Network Service), go to [Log](#)→[Recent calls](#)→[Received calls](#).

Dialed numbers

To view the 20 phone numbers that you have most recently called or attempted to call, go to [Log](#)→[Recent calls](#)→[Dialed nos.](#)

Erasing recent call lists

- To clear all recent call lists, select [Options](#)→[Clear recent calls](#) in the Recent calls main view.
- To clear one of the call registers, open the register you want to erase and select [Options](#)→[Clear list](#).
- To clear an individual event, open a register, scroll to the event, and press .

Call duration

Allows you to view the duration of your incoming and outgoing calls.



Note: The actual time invoiced for calls by your service provider may vary, depending on network features, rounding off for billing, and so forth.

Erasing call duration timers - Select [Options](#)→[Clear timers](#). For this you need the lock code. See ["Security" on page 71](#).

Viewing the general log

In the general log, for each communication event, you can see the sender or recipient name, phone number, name of the service provider, or access point. See Fig. 9, p. 21.

Sub-events, such as a text message sent in more than one part and packet data connections, are logged as one communication event.

Filtering the log

- 1 Select **Options**→ **Filter**. A list of filters opens.
- 2 Scroll to a filter and press **Select**.

Erasing the contents of the log

- To erase all the log contents, Recent calls register, and Messaging delivery reports permanently, select **Options**→ **Clear log**. Confirm by pressing **Yes**.

Packet data counter and connection timer

- To view how much data, measured in kilobytes, has been transferred and how long a certain GPRS connection has lasted, scroll to an Incoming or Outgoing event with the access point icon  and select **Options**→ **View details**.

Log settings

- Select **Options**→ **Settings**. The list of settings opens.
 - **Log duration** - The log events remain in the phone memory for a set number of days after which they are automatically erased to free memory. If you select **No log**, all the log contents, Recent calls register, and Messaging delivery reports are permanently deleted.
 - **Show call duration**. See "Call duration" on page 20.

Go to **Menu**→ **Log** and press .




Fig. 9 General log of communication events.

Personal information



Contacts

In Contacts, you can store and manage contact information, such as names, phone numbers, and addresses.

You can also add a personal ringing tone, voice tag, or a thumbnail image to a contact card. You can create contact groups, which allow you to send text messages or e-mail to many recipients at the same time.

Contact information can only be sent to or received from compatible devices.

Options in the Contacts directory: [Open](#), [Call](#), [Create message](#), [New contact](#), [Edit](#), [Delete](#), [Duplicate](#), [Add to group](#), [Belongs to groups](#), [Mark/Unmark](#), [Copy to SIM direct.](#), [Go to web address](#), [Send](#), [Contacts info](#), [SIM directory](#), [Settings](#), [Help](#), and [Exit](#).

Options when editing a contact card: [Add thumbnail](#) / [Remove thumbnail](#), [Add detail](#), [Delete detail](#), [Edit label](#), [Help](#), and [Exit](#).

Creating and editing contact cards

- 1 Press  in standby mode or go to [Menu](#)→[Contacts](#).
- 2 Open Contacts and select [Options](#)→[New contact](#).
- 3 Fill in the fields you want and press [Done](#).

- **To edit contact cards**, [See "Actions common to all applications" on page 12.](#)
- **To delete contact cards**, in the Contacts directory, scroll to the contact card and select [Options](#)→[Delete](#).
- **To attach a small thumbnail image to a contact card**, open a contact card, select [Options](#)→[Edit](#) and then select [Options](#)→[Add thumbnail](#). The thumbnail image is also shown when the contact is calling you. After you attach a thumbnail image to a contact card, you can select [Add thumbnail](#) to replace the image with a different thumbnail or [Remove thumbnail](#) to remove the thumbnail from the contact card.
- **To assign default numbers and addresses to a contact card**, open a contact card and select [Options](#)→[Defaults](#). A pop-up window opens, listing the different options.

Copying contacts between the SIM card and phone memory

- To copy names and numbers from a SIM card to your phone, select **Options**→ *SIM directory*, scroll to the name(s) you want to copy and select **Options**→ *Copy to Contacts*.
- If you want to copy a phone, fax, or pager number from Contacts to your SIM card, go to Contacts, open a contact card, scroll to the number, and select **Options**→ *Copy to SIM direct*.

Adding a ringing tone for a contact card or group

You can set a ringing tone for each contact card and group. When that contact or group member calls you, the phone plays the chosen ringing tone (if the caller's telephone number is sent with the call and your phone recognises it).

- 1 Press  to open a contact card or go to the Groups list and select a contact group.
 - 2 Select **Options**→ *Ringling tone*. A list of ringing tones opens.
 - 3 Use the scroll key to select the ringing tone you wish to use for the contact or group and press **Select**.
- To remove the ringing tone, select *Default tone* from the list of ringing tones.

Voice dialling

You can make a phone call by saying a voice tag that has been added to a contact card. Any spoken word(s) can be a voice tag.

- When recording, hold the phone at a short distance away from your mouth. After the starting tone, clearly pronounce the word, or words, you want to record as a voice tag.

Before using voice tags, note that:

- Voice tags are not language-dependent. They are dependent on the speaker's voice.
- You must say the name exactly as you said it when you recorded it.



Tip! For an individual contact, the phone uses the ringing tone that was assigned last. So, if you first change a group ringing tone and then the ringing tone of a single contact that belongs to that group, the ringing tone of the single contact is used.

- Voice tags are sensitive to background noise. Record voice tags and use them in a quiet environment.
- Very short names are not accepted. Use long names and avoid similar names for different numbers.



Note: Using voice tags may be difficult in a noisy environment or during an emergency, so you should not rely solely upon voice dialling in all circumstances.

Adding a voice tag to a phone number

Voice tags can only be added to phone numbers stored in the phone's memory. [See "Copying contacts between the SIM card and phone memory" on page 23.](#)

- 1 In the Contacts main view, scroll to the contact that you want to add a voice tag to, and press  to open the contact card.
- 2 Scroll to the number that you want to add the voice tag to, and select **Options** → *Add voice tag*.
- 3 Press **Start** to record a voice tag. After the starting tone, clearly pronounce the word(s) you want to record as a voice tag.
- 4 After recording, the phone plays the recorded tag and the note *Playing voice tag* is displayed.
- 5 When the voice tag has been successfully saved, the note *Voice tag saved* is displayed and a beep sounds. A symbol  can be seen next to the number in the contact card.

Making a call by saying a voice tag

- 1 In standby mode, press and hold . A short tone is played and the note *Speak now* is displayed.
- 2 When you are making a call by using a voice tag, hold the phone at a short distance away from your mouth and face and pronounce the voice tag clearly.
- 3 The phone plays the original voice tag, displays the name and number, and after a few seconds dials the number of the recognised voice tag.
 - If the phone plays the wrong voice tag, or you want to retry voice dialling, press **Retry**.

Voice dialling cannot be used when a data call or a GPRS connection is active.

Assigning speed dialling keys

Speed dialling is a quick way to call frequently used numbers. You can assign speed dialling keys to eight phone numbers. Number 1 is reserved for the voice mailbox.

- 1 Open the contact card for which you want a speed dialling key and select **Options**→ *Assign speed dial*. The speed dialling grid opens, showing you the numbers from 1-9.
- 2 Scroll to a number and press **Assign**. When you return to the contact information view, you can see the speed dial icon next to the number.
- To call the contact by speed dialling, go to standby mode and press the speed dialling key and .

Viewing subscribed contacts

In the Contacts directory, scroll right to the second tab to open the subscribed contacts list. This list allows you to view presence data, including availability and instant messaging (chat) status, for all subscribed contacts. [See "Presence \(Network Service\)" on page 26.](#) [See "Chat \(Network Service\)" on page 92.](#)

 Options in the Subscribed contacts view: *Open, Call, Create message, Open conversation, Unsubscribe, Subscribe new, Mark/Unmark, MyPresence, Settings, Help, and Exit.*

Managing contact groups

Creating contact groups

- 1 In the Contacts directory, press  to open the Groups list.
- 2 Select **Options**→ *New group*.
- 3 Write a name for the group or use the default name *Group 1* and press **OK**.

 Options in the Groups list view: *Open, New group, Delete, Rename, Ringing tone, Contacts info, Settings, Help, and Exit.*

Adding members to a group

- 1 In the Contacts directory, scroll to the contact you want to add to a group and select **Options**→ *Add to group*. A list of available groups opens.
- 2 Scroll to the group to which you want to add the contact and press .

← Go to **Menu** →  **Presence**.

Options in the Presence view: [Open](#), [My availability](#), [Viewers](#), [Update presence](#), [Login](#), [Logout](#), [Settings](#), [Help](#), and [Exit](#).




Fig. 10 The Private Presence view.

Presence (Network Service)

Use Presence to inform others when, where and how you want to be contacted. Presence allows you to view and create a dynamic profile of your contact details, visible to other users of the service, to share information or control services. Presence information can include your availability, whether you prefer people to call or send messages, where you are and what you are doing. See Fig. 10, p. 26.

Before you can use Presence, you need to find a service that you want to use and then save the settings of that service. You may receive the settings in a special text message, called a smart message, from the service provider that offers the Presence service. [See "Receiving smart messages" on page 51.](#) For more information, contact your service provider.

The Presence application allows you to change your own published information and manage who is authorised to see your presence. To view the presence information of others, you must use Contacts. [See "Contacts" on page 22.](#)

Changing your availability information

Select **Options** → [My availability](#) and select:

- **Available** - You are available for people to call or send you messages, for example, your phone is in general profile. [See "Profiles" on page 79.](#)
- **Busy** - You may be available for people to call or send you messages, for example, your phone is in meeting profile.
- **Not available** - You are not available for people to call or send you messages, for example, your phone is in silent profile.

Changing who can view your Presence information

Select **Options** → [Viewers](#) and select:

- **Public pres.** - Displays limited information, for managing ways for people to contact you. This is available to anyone you have not blocked.
 - [My availability](#) - Select [Available](#), [Busy](#), or [Not available](#).

- *Viewers* - Opens the *Current viewers* view of your *Public pres.* [See "Public viewers" on page 27.](#)
- *Update presence* - Updates your presence information to the presence server.
- *Login / Logout* - Connect to or disconnect from the presence server. [See "Chat and Presence servers" on page 98.](#)
- *Settings* - To manage the publishing of your presence information.
- *Private pres.* - Displays private information, so you can share more personal information. This is only available to those that you have authorised to view your private information. You can select the following options:
 - *My availability* - Select *Available*, *Busy*, or *Not available*.
 - *My presence msg.* - You can write a text message of up to 40 characters to describe your current availability.
 - *My presence logo* - You can add a logo to your availability information. Logo files are stored in the Gallery. [See "Gallery" on page 40.](#)
 - *Viewers* - Opens the *Private list* view of your *Private pres.* [See "Private viewers" on page 28.](#)
 - *Update presence* - Updates your presence information to the presence server.
 - *Login / Logout* - Connect to or disconnect from the presence server. [See "Chat and Presence servers" on page 98.](#)
 - *Settings* - To manage the publishing of your presence.
- *Blocked pres.* - Displays a screen containing no personal details. [See "Blocked viewers" on page 28.](#)

Public viewers

Go to *Public pres.* and select **Options**→ *Viewers*→ *Current viewers* to see the names, phone numbers, or user IDs of the viewers who you do not allow to view your private presence messages, but who are currently viewing your public presence. You can scroll to a viewer, press **Options**, and select:

- *Add to private list* - Allows the viewer to also see your private presence.
- *Block* - Prevents the viewer from seeing your presence information.

- [Add to contacts](#) - Adds the viewer to your Contacts directory.
- [Refresh lists](#) - Connect to the presence server to update the viewer lists. This option is only available when you are offline.

Private viewers

Go to [Private pres.](#) and select [Options](#)→[Viewers](#)→[Private list](#) to see the names, phone numbers, or user IDs of the viewers who you allow to view your private presence messages. To prevent a viewer from seeing your private presence messages, scroll to the viewer and press . You can scroll to a viewer, press [Options](#), and select:

- [Add new](#) - Add a new viewer manually or from your Contacts directory.
You can only select a contact who has a user ID in the contact card.
- [Block](#) - Prevents the viewer from seeing your presence information.
- [Add to contacts](#) - Adds the viewer to your Contacts directory.
- [Remove from list](#) - Removes the viewer from the private list. The option is available also when there are marked items as selected. If the list is empty the option is not available.
- [View details](#) - Shows the user ID information of the viewer.
- [Refresh lists](#) - Connect to the presence server to update the viewer lists. This option is only available when you are offline.

Blocked viewers

Go to [Options](#)→[Viewers](#)→[Blocked pres.](#) to see the viewers you prevented from seeing your public and private presence messages. To allow a viewer to see your presence information, scroll to a viewer and press . You can scroll to a viewer, press [Options](#), and select:

- [Add to private list](#) - Allows the viewer to also see your private presence.
- [Add new](#) - Add a new viewer manually or from your Contacts directory.
You can only select a contact who has a user ID in the contact card.
- [Add to contacts](#) - Adds the viewer to your Contacts directory.
- [View details](#) - Shows the user ID information of the viewer.
- [Refresh lists](#) - Connect to the presence server to update the viewer lists. This option is only available when you are offline.

Updating your Presence information

Go to **Menu**→ **Presence**.

Once the connection has been established:

- 1 Key in your user ID and password and press  to login.
You obtain the user ID and password from your service provider.
- 2 Select **Options**→ **Update presence**. The option is available when you are logged into the server and have changed your presence information in **Private pres.** or **Public pres.** view and not updated it.
- 3 To logout, select **Options**→ **Logout**.

Presence settings

Select **Options**→ **Settings** from the Presence main menu.

[See "Chat and Presence servers" on page 98.](#)

- **Show to** - Select:
 - **Private & public** - Both public and private presence is published.
 - **Private viewers** - Only private viewers can see your presence information.
 - **Public viewers** - Both public and private viewers see your public presence information.
 - **No one** - Your presence information is not published.
- **Sync. with Profiles** - Defines which Presence attributes are changed when you change your profile. Select:
 - **Off** - The presence attributes are not changed, even if you change your profile.
 - **Presen. msg. only** - Both **My availability** and **My presence msg.** are changed when you change your profile.
 - **Availability only** - **My presence msg.** is not changed when you change your profile.
 - **Private msg. only** - **My availability** is not changed when you change your profile.

Go to **Menu** → **Positioning**.



Positioning (Network Service)

Positioning allows the network to detect the position of your phone. By enabling or disabling **Positioning**, you choose when your position information is provided to the network.

To enable **Positioning** in your phone, select **Settings** → **Positioning** → **On**.

When you receive a **Position request**, a message is displayed showing the service that is making the request. Press **Accept** to allow your position information to be sent, or press **Reject** to deny the request.

Position request messages are logged in the **Recv. requests** list. To view them, select **Menu** → **Positioning** → **Recv. requests**. The icon beside each request indicates whether the request is new, rejected, or accepted. If you want to see details of a request, scroll to the request and press . If you want to clear the **Recv. requests** list, select **Options** → **Clear list**.



Calendar

In Calendar, you can keep track of your appointments, meetings, birthdays, anniversaries, and other events. You can also set a calendar alarm to remind you of upcoming events. Calendar uses shared memory. [See "Shared memory" on page 14.](#)

Creating calendar entries

- 1 Go to **Menu** → **Calendar**
- 2 Select **Options** → **New entry** and select:
 - **Meeting** to remind you of an appointment that has a specific date and time.
 - **Memo** to write a general entry for a day.
 - **Anniversary** to remind you of birthdays or special dates. Anniversary entries are repeated every year.

- 3 Fill in the fields. Use the scroll key to move between fields.
- **Subject / Occasion** - Write a description of the event.
 - **Location** - The place of a meeting, optional.
 - **Start time, End time, Start date, and End date.**
 - **Alarm** - Press  to activate the fields for **Alarm time** and **Alarm date**.
 - **Repeat** - Press  to change the entry to be repeating. Shown with  in the Day view.
 - **Repeat until** - You can set an ending date for the repeated entry, for example, the ending date of a weekly course you are taking. This option is shown only if you have selected to repeat the event.
 - **Synchronisation - Private** - After synchronisation the calendar entry can be seen only by you and it will not be shown to others even if they have online access to view the calendar. **Public** - The calendar entry is shown to others who have access to view your calendar online. **None** - The calendar entry will not be copied when you synchronise your calendar.
- 4 To save the entry, press **Done**.

If you are editing or deleting a repeated entry, choose how you want the changes to take effect: **All occurrences** - all repeated entries are changed / **This entry only** - only the current entry will be changed.

Calendar views

Press  in the Month, Week, or Day views to automatically highlight today's date.

To write a calendar entry, press any number key ( - ) in any calendar view. A Meeting entry is opened and the characters you keyed in are added to the **Subject** field.

- To go to a certain date, select **Options** → **Go to date**. Write the date and press **OK**.
- Icons in Day and Week views:  - **Memo**, and  - **Anniversary**.
- Synchronisation icons in Month view:
 -  - **Private**,
 -  - **Public**,
 -  - **None**, and
 -  - the day has more than one entry.

 Options in the different calendar views: **Open, New entry, Week view / Month view, Delete, Go to date, Send, Settings, Help, and Exit.**



To-do

In To-do you can keep a list of tasks that you need to do. The To-do list uses shared memory. See ["Shared memory" on page 14](#).

Go to **Menu** → **To-do**.

- 1 To start to write a to-do note, press any digitkey (-). The editor opens and the cursor blinks after the letters you have keyed in.
- 2 Write the task in the **Subject** field. Press to add special characters.
 - To set the due date for the task, scroll to the **Due date** field and key in a date.
 - To set a priority for the to-do note, scroll to the **Priority** field and press .
- 3 To save the to-do note, press **Done**. If you remove all characters and press **Done**, the note will be deleted, even if you edit a previously saved note.
 - To open a to-do note, scroll to it and press .
 - To delete a to-do note, scroll to it and select **Options** → **Delete** or press .
 - To mark a to-do note as completed, scroll to it and select **Options** → **Mark as done**.
 - To restore a to-do note, select **Options** → **Mark as not done**.

Importing data from compatible Nokia phones

You can move calendar, contacts, and to-do data from compatible Nokia phones to your phone using the Nokia PC Suite 6.1 Content Copier application on a compatible PC. Instructions for using the application can be found in the help function of PC Suite on the CD-ROM.

Multimedia

Camera

With the **Camera** application you can take pictures and record videos while on the move. The images are automatically saved in the Gallery application, where you can rename them and organise them in folders. You can also send images in a multimedia message, as an e-mail attachment, or via a Bluetooth connection. The camera produces JPEG images and video clips are recorded in the 3GPP file format with the .3gp file extension.

➡ Press  in standby mode or go to **Menu** → **Camera**.

Taking pictures

- 1 Press  in standby mode and press  or  to move to the *Image* tab. The **Camera** application opens and you can see the view to be captured. You can see the viewfinder and the cropping lines, which show you the image area to be captured. You can also see the image counter, which shows you how many images, depending on the selected picture quality, fit in the memory of your phone or memory card, if you use one.
- 2 Press  to zoom in on your subject before taking the picture. Press  to zoom out again. The zoom indicator on the display shows the zoom level.
- 3 To take a picture, press . Do not move the phone before the **Camera** application starts to save the image. The image is saved automatically in the Gallery. [See "Gallery" on page 40.](#)



Tip! The resolution of a zoomed picture is lower than that of a non-zoomed picture, but the image remains the same size. You may notice the difference in image quality if viewed on a PC, for example.

▶ Options before taking a picture: *Capture*, *Activate night mode* / *Deact. night mode*, *Go to Gallery*, *Self-timer*, *Settings*, *Help*, and *Exit*.

Options after a picture has been taken: *Image*, *Delete*, *Send*, *Set as wallpaper*, *Rename image*, *Go to Gallery*, *Settings*, *Help*, and *Exit*.

Camera goes into battery saving mode if there have been no key presses within a minute. To continue taking pictures, press .

After the image has been saved:

- If you do not want to save the image, select **Options**→ *Delete*.
- To return to the viewfinder to take a new picture, press .

You can insert an image into a contact card. [See "Creating and editing contact cards" on page 22.](#)

Self-timer

Use the self-timer to delay the taking of a picture, so that you can include yourself in the picture.

- 1 Select **Options**→ *Self-timer*.
- 2 Select the delay *10 seconds*, *20 seconds*, or *30 seconds*.
- 3 Press *Activate*. The camera will take the picture after the selected delay has elapsed.

Settings

In the **Camera** application settings, you can adjust the image quality setting, change the default image name, and change the memory location of saved images.

- 1 Select **Options**→ *Settings*→ *Image*.
- 2 Scroll to the setting you want to change:
 - *Image quality* - *High*, *Normal*, and *Basic*. The better the image quality, the more memory the image consumes.
 - *Default image name* - By default, **Camera** names images in the format 'Image.jpg'. *Default image name* allows you to set a name for the images stored.
 - *Memory in use* - Select whether you want to store your images in the phone memory or on the memory card, if you use one.

Recording videos

Press **Camera** in standby mode and press  or  to move to the *Video* tab.

- Press  to start recording.
- To pause recording at any time, press . Press  again, to resume recording.
- Press  to zoom in on your subject before, or during, recording. Press  to zoom out again.
- Press  to stop recording.

The video clip is saved to either the phone's memory or the memory card, depending on the setting of your *Memory in use*. See "[Setting up your Video recorder](#)" on page 35.

- To immediately play the video clip you just recorded, select **Options**→ *Play*.
- To play previously saved video clips, go to the Gallery. See "[Gallery](#)" on page 40.

Setting up your Video recorder

Use the following settings to define how videos are recorded.

- 1 Select **Options**→ *Settings*→ *Video*.
- 2 Scroll to the setting you want to change:
 - *Length* - Select:
 - *Maximum* - The length of the video recording is restricted to 10 minutes.
 - *Short* - To record video clips up to 95 kB in size, which relates to approximately 10 seconds in duration, so that they can be conveniently sent as a multimedia message.
 - *Video resolution* - Select 128x96 or 176x144.
 - *Default video name* - Define a default name.
 - *Memory in use* - Define the memory store. Choices are phone's memory or memory card, if one is used.

 Options before recording a video: *Record*, *Activate night mode* / *Deact. night mode*, *Mute* / *Unmute*, *Go to Gallery*, *Settings*, *Help*, and *Exit*.

 Options after you have recorded a video: *New*, *Play*, *Delete*, *Send*, *Rename*, *Go to Gallery*, *Settings*, *Help*, and *Exit*.

Options when viewing an image: [Send](#), [Set as wallpaper](#), [Rotate](#), [Zoom in](#), [Zoom out](#), [Full screen](#), [Delete](#), [Rename](#), [View details](#), [Add to 'Go to'](#), [Help](#), and [Exit](#).

Viewing images

Pictures taken with the **Camera** application are stored as images in the Gallery. [See "Gallery" on page 40.](#) Images can be sent to you in a multimedia or picture message, as an e-mail attachment, or via Bluetooth. After receiving an image in Inbox, you need to save it in the phone memory or on a memory card. You can save graphics sent to you in picture messages to the Picture messages folder. [See "Picture messages folder" on page 41.](#)

Select an image from the list of images in the **Images** folder in the Gallery to start the image viewer and display the image.

When viewing an image, pressing  or  takes you to the next or previous image in the current folder.

In the images thumbnail view:

- 1 Press  or  to move between the phone and memory card.
- 2 To browse the list of images, press  and .
- 3 Press  to open an image. When the image is open, you can see the name of the image.

You can view animated GIF files in the same way as other images.

Zooming on a saved image

- 1 Select **Options** → [Zoom in](#) or [Zoom out](#). You can see the zooming ratio at the top of the display. [See "Keyboard shortcuts" on page 37.](#)
- 2 Press  to return to the initial view. The zooming ratio is not stored permanently.

Full screen

When you select **Options** → [Full screen](#), the panes around the image are removed so that you can see more of the image. Press  to return to the initial view.

Moving the focus

When you are zooming an image or viewing an image in full screen mode, use the scroll key to move the focus to the left, right, up, or down, so that you can take a closer look at one part of the image, for example, its upper right corner.

Keyboard shortcuts

- Rotate 90 degrees:  - anticlockwise,  - clockwise. The rotation status is not stored permanently.
-  - zoom in,  - zoom out, press and hold to return to the normal view.
-  - change between full screen and normal view.



RealOne Player™

With RealOne Player™, you can play local media files stored in the phone memory, or memory card, or stream media files over the air from a streaming link. The streaming link can be activated during a browsing session or stored in the phone memory, or memory card.

Media files are video, music or audio clips. Files with the extensions .3gp, .amr, .mp4, .rm and .ram are supported by RealOne Player.

RealOne Player does not necessarily support all file formats or all the variations of a file formats. For example, RealOne Player will attempt to open all .mp4 files. However, some .mp4 files may include content that is not compliant with 3GPP standards and, therefore, is not supported by this phone. In this case, the operation might fail and result in partial playback or in an error message.

RealOne Player uses shared memory. [See "Shared memory" on page 14.](#)

 Go to [Menu](#) →
[RealOne Player](#).

Options in RealOne Player when a clip has been selected: *Play, Continue, Stop, Mute, Unmute, Clip details, Send, Settings, Help, and Exit.*



Fig. 11 The RealOne Player main view.

Playing media files

- To play a media file stored in your phone's memory or memory card, select **Options**→**Open** and:
 - Most recent clips** - To play one of the last 6 files played in RealOne Player, or
 - Saved clip** - To play a file saved in the Gallery. [See "Gallery" on page 40.](#) Scroll to a file and press to play the file.
- To stream content over the air:
 - Select a streaming link saved in the Gallery. Before your live content begins streaming, your phone will connect to the site and load the file.
 - Open the link to a file in the browser.

To stream live content, you must first configure your default access point. [See "Access points" on page 66.](#)

Many service providers will require you to use an Internet Access Point (IAP) for your default access point. Other service providers allow you to use a WAP access point. Contact your service provider for more information.

In RealOne Player, you can only open an rtsp:// URL address. You cannot open an http:// URL address, however RealOne Player will recognise an http link to a .ram file since a .ram file is a text file containing a rtsp link.

Shortcuts during play

When a media file is playing use the scroll key to seek (move quickly through the media file), and to mute the sound, as follows:

Press and hold to seek forwards, or press and hold to seek backwards through the media file.

Press and hold until the indicator is displayed to mute the sound.

Press and hold until you see the indicator to turn on the sound.

Changing the settings

Select **Options** → *Settings* then either *Video* or *Connection*.

Press  or  to move between the different setting tabs for *Video* and *Connection*.

Select *Video* to change the following list of settings:

- *Contrast* - Open the slider view to change the contrast.
- *Repeat* - Choose *On* to have the playing video or audio file restart automatically once it has finished.

Select *Connection* to change the connection settings.



Movie director

Use **Movie director** to create edited video clips which may contain video, sound, and text. Editing is carried out automatically according to the style that you select. The style determines the transitions and visual effects that are used in the video clip.

 Go to **Menu** → **Movie director**.

Open **Movie director** and press  or  to move between the  tab and the  tab.

In the  tab, you can select:

- *Quick muvee* - Creates video clips suitable to be sent via multimedia (MMS). You can select several video clips and the style you want to apply to them. The duration of the *Quick muvee* video clip is typically less than 10 seconds.
- *Custom muvee* - You can select video clips and apply a style, music and message, set the duration and preview the video clip before saving. The options *Select* video, *Select* style, *Select* music and *Select* message become available when you scroll through the list.
 - *Select* video - Select the source file or files you want to use. Select *Mark/Unmark*, *Play* or *Capture*.
 - *Select* style - Select a style from the list. Styles determine the effects and message caption. Each style is associated with default music and message text.

- *Select* music - Select a music clip from the list.
- *Select* message - Adds a caption to the beginning and ending of the video clip. You can enter a message or select one from the template. You can edit the default message text.
- *Create muvee* - You are prompted to set the duration for the video clip. Select *Multimedia message* to create a video size suitable to be sent via MMS, *Same as music* to create a video of the same duration as the selected music clip or *User defined* to manually enter the video duration.
After the video preview is prepared the *Preview muvee* view opens, where you can *Play, Recreate* (to make a new variation of the video clip) and *Save* the new video clip.
- *Style downloads* - Download and install new styles.
- *Settings* - Scroll to the setting you want to change:
 - *Memory in use* - Select *Phone memory* or *Memory card*
 - *Resolution* - Select *High, Low* or *Automatic*
 - *Default muvee name* - Enter a default name for your video clips.

The  tab contains a list of video clips that you can *Play, Send, Rename* and *Delete*.



Gallery

← Go to **Menu** →
Gallery.

Use the Gallery to store and organise your images, sound clips, playlists, and video clips, streaming links and RAM files.

Gallery uses shared memory. See "[Shared memory](#)" on page 14.

Open the Gallery to see a list of the folders in the phone memory. Press  to see the folders on the memory card, if you use one.

Select a folder *Images, Sound clips, or Video clips* (or other folder that you have created) and press  to open it.

In the open folder you can see:

- an icon depicting the type of each file in the folder, or in the case of an image, a small thumbnail picture; a preview of the image
- the name of the file
- the date and time a file was saved or the size of the file
- subfolders, if present.

You can browse, open, and create folders, mark, copy and move items to folders. [See "Actions common to all applications" on page 12.](#)

Opening files

Select any file and press  to open it. Each file will open in its corresponding application as follows:

- Images - Open in the Image viewer. [See "Viewing images" on page 36.](#)
- Sound clips - Open and play in the RealOne Player application. [See "RealOne Player™" on page 37.](#)
- Video clips, RAM files, and streaming links - Open and play in the RealOne Player application. [See "RealOne Player™" on page 37.](#)
- Subfolders - Open to display contents.

Other default folders

Picture messages folder

Use this folder to store pictures sent to you in picture messages.

- Select the folder *Images* → *Picture msgs.*

To save a picture that you have received in a picture message, go to **Messaging** → *Inbox*, open the message, and select **Options** → *Save picture.*

Wallpapers folder

Use this folder to store pictures that you want to use as background images for multimedia messages.

 Options: *Open* (folder or item), *Send*, *Delete*, *Create new*, *Move to folder*, *Copy to folder*, *New folder*, *Mark/Unmark*, *Edit*, *Rename*, *Gallery downloads*, *Image uploader*, *View details*, *Add to 'Go to'*, *Settings*, *Help*, and *Exit*.

 Options in the Picture messages folder: *Open*, *Send*, *Delete*, *Mark/Unmark*, *Rename*, *View details*, *Help*, and *Exit*.

- Select the folder *Images*→ *Wallpapers*.

Presence logos folder

Use this folder to store logos for Presence. [See "Presence \(Network Service\)" on page 26.](#)

- Select the folder *Images*→ *Presence logos*.

Downloading files

To download files into the Gallery using the browser:

- Select **Options**→ *Gallery downloads* and choose from *Graphic downloads*, *Video downloads*, or *Tone downloads*. The browser opens and you can choose a bookmark for the site to download from. [See "Viewing bookmarks" on page 104.](#)

To download files, you must first configure your default access point. [See "Access points" on page 66.](#)

Once items have been downloaded, the browser closes and the phone returns to the Gallery view.

Uploading images to an image server (Network Service)

You can send your pictures to an image server to allow others to share your pictures online.

Before you can upload images, you must enter the settings for the image server. [See "Setting up the image server" on page 43.](#) You can get these settings from your service provider.

- 1 Select **Options**→ *Image uploader*.
- 2 To begin an upload, mark the images and select *Upload*.
- 3 Enter a name for the folder on the image server that the images will be stored in and press .

Setting up the image server

- 1 Select **Settings**→ *Image servers* and press . Fill in the details for each field. [See "Access points" on page 66.](#)
- 2 Press .



Messaging

← Go to **Menu** →
Messaging.

In Messaging you can create, send, receive, view, edit, and organise: text messages, multimedia messages, e-mail messages, and smart messages, special text messages containing data. You can also receive messages and data via a Bluetooth connection, receive service messages, cell broadcast messages, and send service commands.



Note: Picture message function can be used only if it is supported by your network operator or service provider. Only devices that offer picture message features can receive and display picture messages.

Text messages and multimedia messages (MMS) use shared memory. [See "Shared memory" on page 14.](#)

Options in the Messaging main view: [Create message](#), [Connect](#) (shown if you have defined settings for the mailbox), or [Disconnect](#) (shown if there is an active connection to the mailbox), [SIM messages](#), [Cell broadcast](#), [Service command](#), [Settings](#), [Help](#), and [Exit](#).

When you open Messaging, you can see the [New message](#) function and a list of default folders:



Inbox - Contains received messages except e-mail and cell broadcast messages. E-mail messages are stored in the [Mailbox](#). You can read cell broadcast messages by selecting [Options](#) → [Cell broadcast](#).



My folders - For organising your messages into folders.



Mailbox - When you open this folder, you can either connect to your remote mailbox to retrieve your new e-mail messages or view your previously retrieved e-mail messages offline. After you have defined settings for a new mailbox, the name given to that mailbox will replace [Mailbox](#) in the main view. [See "Settings for e-mail" on page 59.](#)



Drafts - Stores draft messages that have not been sent.



Sent - Stores the last 15 messages that have been sent. You can change the number of messages to be saved. [See "Settings for the Other folder" on page 61.](#)

Messages or data that have been sent via a Bluetooth connection are not saved in the Draft or Sent folders.



Outbox - Is a temporary storage place for messages waiting to be sent.



Reports (Network Service) - You can request the network to send you a delivery report of the text messages, smart messages, and multimedia messages you have sent. To turn on delivery report reception, select **Options** → *Settings* → *Text message* or *Multimedia message*, scroll to *Receive report*, and select *Yes*.

Receiving a delivery report of a multimedia message that has been sent to an e-mail address might not be possible.



Note: When sending messages, your device may display the words "*Data Sent!*". This is an indication that the message has been sent by your device to the message centre number programmed into your device. This is not an indication that the message has been received at the intended destination. For more details about messaging services, check with your service provider.

Before you create a multimedia message, write an e-mail, or connect to your remote mailbox, you must have the correct connection settings in place. [See "Settings needed for e-mail" on page 50.](#) [See "Settings needed for multimedia messaging" on page 50.](#)

Writing text

Using traditional text input

The indicator  is shown on the top right of the display when you are writing text using traditional text input.

- Press a number key ( - ), repeatedly until the desired character appears.
Note that there are more characters available for a number key than are printed on the key.



Icons: **ABC** and **abc** indicate the selected case. **Abc** means that the first letter of the next word is written in upper case, and all other letters will automatically be written in lower case. **123** indicates number mode.

- To insert a number, press and hold the number key.
To switch between letter and number mode, press and hold
- If the next letter is located on the same key as the present one, wait until the cursor appears (or press to end the time-out period), and then key in the letter.
- If you make a mistake, press to remove a character. Press and hold to clear more than one character.
- The most common punctuation marks are available under . Press repeatedly to reach the desired punctuation mark.
Press to open a list of special characters. Use the scroll key to move through the list and press **Select** to select a character.
- To insert a space, press . To move the cursor to the next line, press three times.
- To switch between upper and lower case, press .

Using predictive text input

You can key in any letter with a single keypress using the predictive text input. To activate predictive text input, press and select **Dictionary on**. This will activate predictive text input for all editors in the phone. The indicator is shown at the top of the display. See Fig. 12, p. 47.

- 1 Write the desired word by pressing the keys - . Press each key only once for one letter. The word changes after every key press.

For example, to write 'Nokia' when the English dictionary is selected, press

for N, for o, for k, for i, and for a.

The word suggestion changes after each key press. See Fig. 12, p. 47.

- 2 When you have finished the word, check that it is correct.
 - If the word is correct, you can confirm it by pressing or by pressing to insert a space. The underlining disappears and you can begin to write a new word.
 - If the word is not correct, you have the following options:
 - Press repeatedly to view the matching words the dictionary has found one by one.
 - Press and select **Dictionary** → **Matches** to view a list of matching words. Scroll to the word you want to use and press to select it.
 - If the ? character is shown after the word, the word you intended to write is not in the dictionary. To add a word to the dictionary, press **Spell**, key in the word (max. 32 letters) using traditional text input, and press **OK**. The word is added to the dictionary. When the dictionary becomes full, a new word replaces the oldest added word.
 - To remove the ? and clear characters one by one from the word, press .

Tips on using predictive text input

- To erase a character, press . Press and hold to clear more than one character.
- To change between the different character cases **Abc**, **abc**, and **ABC**, press . Note that if you press twice quickly the predictive text input is turned off.
- To insert a number in letter mode, press and hold the desired number key, or press and select number mode, key in the numbers you want, and press **OK**.
- The most common punctuation marks are available under . Press repeatedly to reach the desired punctuation mark.




Fig. 12 Predictive text input.

Press  to open a list of special characters. Use the scroll key to scroll through the list and press **Select** to select a character. Or press  and select *Insert symbol*. The predictive text input will try to guess which commonly used punctuation mark (.,?!') is needed. The order and availability of the punctuation marks depend on the language of the dictionary.

- Press  repeatedly to view the matching words the dictionary has found one by one.

When a word has been entered with predictive text on, you can press , select *Dictionary* and select:

- *Matches* - To view a list of words that correspond to your key presses. Scroll to the desired word and press .
- *Insert word* - To add a word (max. 32 letters) to the dictionary by using traditional text input. When the dictionary becomes full, a new word replaces the oldest added word.
- *Edit word*- To open a view where you can edit the word, available only if the word is active (underlined).
- *Off* - To turn off predictive text input for all editors in the phone.

Writing compound words

- Write the first half of a compound word and confirm it by pressing . Write the last part of the compound word and complete the compound word by pressing  to add a space.

Copying text to the clipboard

If you want to copy text to the clipboard, the following are the easiest methods:

- 1 To select letters and words, press and hold . At the same time, press  or . As the selection moves, text is highlighted.
To select lines of text, press and hold . At the same time press  or .
- 2 To end the selection, release pressing the scroll key while still holding .
- 3 To copy the text to the clipboard, while still holding , press **Copy**.

Or, release  and then press it once to open a list of editing commands, for example, *Copy* or *Cut*.

If you want to remove the selected text from the document, press .

- 4 To insert the text into a document, press and hold  and press *Paste*.

Or, press  once and select *Paste*.

Writing and sending messages

Before you can create a multimedia message, or write an e-mail, or connect to your remote mailbox, you must have the correct connection settings in place. [See "Settings needed for e-mail" on page 50.](#) [See "Settings needed for multimedia messaging" on page 50.](#)

- 1 Select *New message*. A list of message options opens. Select:
 - *Create*→ *Text message* if you want to create a text message
To send a picture message, select *Options*→ *Insert*→ *Picture*.
Each picture message is made up of several text messages. Therefore, sending one picture message may cost more than sending one text message.
 - *Create*→ *Multimedia message* if you wish to send a multimedia message (MMS).
Copyright protections may prevent some images, ringing tones, and other content from being copied, modified, transferred or forwarded.
 - *Create*→ *E-mail* to send e-mail. If you have not set up your e-mail account, you will be prompted to do so.
- 2 Press  to select the recipient(s) from the Contacts directory or write the phone number or e-mail address of the recipient in the *To*: field if you are sending an MMS or e-mail to the recipient. Press  to add a semicolon (;) to separate each recipient.
- 3 Press  to move to the message field.
- 4 Write the message.

Your device supports the sending of text messages beyond the normal 160-character limit. If your message exceeds 160 characters, it will be sent as a series of two or more messages. Therefore, sending a message that exceeds 160 characters may cost more.

 Options in the text message editor: *Send*, *Add recipient*, *Insert*, *Delete*, *Check contacts*, *Message details*, *Sending options*, *Help*, and *Exit*.



Tip! Start to key in a name in the *To:* field and select **Options**→ *Check contacts*. The phone will retrieve all matching entries from the Contacts directory. If only one entry is found, it is added automatically. If more than one entry is found, select a contact from the list.

- To add a media object to a multimedia message, select **Options**→ *Insert* → *Image* or *New image*, *Sound clip* or *New sound clip* or *Video clip*. Select the item you wish to add. When sound has been added, the  icon is shown in the navigation bar. If you select *Insert*→ *New sound clip*, Recorder opens and you can record a new sound. The sound is automatically saved and a copy is inserted in the message.
- 5 To send the message, select **Options**→ *Send* or press .

Settings needed for multimedia messaging

You may receive the settings as a smart message from your network operator or service provider. [See "Receiving smart messages" on page 51.](#)

For availability of and subscription to data services, please contact your network operator or service provider.

- Go to **Messaging**→ **Options**→ *Settings*→ *Multimedia message*. Open *Access point in use* and select the access point you created. [See "Settings for multimedia messages" on page 58.](#)

Settings needed for e-mail

Before you can send, receive, retrieve, reply to, and forward e-mail to a separate e-mail account, you must:

- Configure an Internet Access Point (IAP) correctly. [See "Connection settings" on page 66.](#)
- Define your e-mail settings correctly. [See "Settings for e-mail" on page 59.](#)

Follow the instructions given by your remote mailbox and Internet service provider.



Inbox - receiving messages

When there are unread messages in Inbox, the icon changes to .

In Inbox, the message icons tell you what kind of a message it is. Here are some of the icons that you may see:

 for an unread text message and  for an unread smart message

 for an unread multimedia message

 for an unread service message

 for data received via Bluetooth

 for an unknown message type.

Options in Inbox: *Open, Create message, Delete, Message details, Move to folder, Mark/Unmark, Help, and Exit.*

Viewing multimedia objects

- To see what kinds of media objects have been included in the multimedia message, open the message and select **Options**→*Objects*. In the Objects view you can view files that have been included in the multimedia message. You can choose to save the file in your phone or to send it, for example, via Bluetooth to another compatible device.



Important: Multimedia message objects may contain viruses or otherwise be harmful to your device or PC. Do not open any attachment if you are not sure of the trustworthiness of the sender.

Options in the Objects view: *Open, Save, Send, Call, and Exit.*

[See "Certif. management" on page 73.](#)

Receiving smart messages

Your phone can receive many kinds of smart messages, text messages that contain data (also called Over-The-Air (OTA) messages). To open a received smart message, open Inbox, scroll to the smart message () , and press .

- Picture message* - To save the picture in the *Picture messages* folder in the Gallery for later use, select **Options**→*Save picture*.
- Business card* - To save the contact information, select **Options**→*Save business card*.



Tip: If certificates or sound files are attached to business cards, they will not be saved.

- *Ringing tone* - To save the ringing tone to the Gallery, select **Options**→ *Save*.
- *Operator logo* - To save the logo, select **Options**→ *Save*. The operator logo can now be seen in standby mode instead of the network operator's own identification.
- *Calendar entry* - To save the invitation to Calendar, select **Options**→ *Save to Calendar*.
- *Web message* - To save the bookmark, select **Options**→ *Save to bookmarks*. The bookmark is added to the Bookmarks list in browser services.

If the message contains both browser access point settings and bookmarks, to save the data select **Options**→ *Save all*. Or, select **Options**→ *View details* to view the bookmark and access point information separately. If you do not want to save all data, select a setting or bookmark, open the details, and select **Options**→ *Save to Settings* or *Save to bookmarks* depending on what you are viewing.

- *E-mail notification* - Tells you how many new e-mails you have in your remote mailbox. An extended notification may list more detailed information such as subject, sender, attachments, and so on.
- In addition, you can receive a text message service number, voice mailbox number, profile settings for remote synchronisation, access point settings for the browser, multimedia messaging or e-mail, access point login script settings, or e-mail settings. To save the settings, select **Options**→ *Save to SMS sett.*, *Save to Voice mail*, *Save to Settings*, or *Save to e-mail sett.*

Receiving service messages (Network Service)

Service messages are notifications of, for example, news headlines and they may contain a text message or address of a browser service. For availability and subscription, contact your service provider.



My folders

In My folders you can organise your messages into folders, create new folders, and rename and delete folders.



Remote mailbox (Network Service)

When you open this folder, you can either connect to your remote mailbox to:

- retrieve new e-mail headings or messages, or
- view your previously retrieved e-mail headings or messages offline.

If you select *New message* → *Create* → *E-mail* or *Mailbox* in the Messaging main view and you have not set up your e-mail account, you will be prompted to do so. [See "Settings needed for e-mail" on page 50.](#)

When you create a new mailbox, the name you give to the mailbox automatically replaces *Mailbox* in the Messaging main view. You can have several mailboxes (max. six).

Opening the mailbox

When you open the mailbox, you can choose whether you want to view the previously retrieved e-mail messages and e-mail headings offline or connect to the e-mail server.

- When you scroll to your mailbox and press , the phone asks you if you want to *Connect to mailbox?* Select *Yes* to connect to your mailbox or *No* to view previously retrieved e-mail messages offline.
- Another way to start a connection is to select *Options* → *Connect*.

Retrieving e-mail messages from the mailbox

- If you are offline, select *Options* → *Connect* to start a connection to a remote mailbox.

- 1 When you have an open connection to a remote mailbox, select **Options**→ *Retrieve e-mail*→:
 - *New* - To retrieve all new e-mail messages to your phone.
 - *Selected* - To retrieve only the e-mail messages that have been marked. Use the *Mark/Unmark* → *Mark / Unmark* commands to select messages one by one. [See "Actions common to all applications" on page 12.](#)
 - *All* - To retrieve all messages from the mailbox.
 To cancel retrieving, press **Cancel**.
- 2 After you have retrieved the e-mail messages, you can continue viewing them online. Select **Options**→ *Disconnect* to close the connection and to view the e-mail messages offline.
- 3 To open an e-mail message, scroll to the e-mail you want to view and press . If the e-mail message has not been retrieved (arrow in the icon is pointing outwards) and you are offline and select *Open*, you will be asked if you want to retrieve this message from the mailbox.
 - To view e-mail attachments, open a message that has the attachment indicator  and select **Options**→ *Attachments*. In the Attachments view, you can retrieve, open, or save attachments, in supported formats. You can also send attachments via Bluetooth.
 If your mailbox uses the IMAP4 protocol, you can decide whether to retrieve e-mail headings only, messages only, or messages and attachments. With the POP3 protocol, the options are e-mail headings only or messages and attachments. [See "Settings for e-mail" on page 59.](#)



Important: Multimedia message objects may contain viruses or otherwise be harmful to your device or PC. Do not open any attachment if you are not sure of the trustworthiness of the sender.

Deleting e-mail messages

- To delete an e-mail from the phone while still retaining it in the remote mailbox:

Select **Options**→ *Delete*→ *Phone only*.

The phone mirrors the e-mail headings in the remote mailbox. So, although you delete the message content, the e-mail heading stays in your phone. If you want to remove the heading as well, you have to first delete the e-mail message from your remote mailbox and then make a connection from your phone to the remote mailbox again to update the status.

- To delete an e-mail from both the phone and the remote mailbox:

Select **Options**→ *Delete*→ *Phone and server*.

If you are offline, the e-mail will be deleted first from your phone. During the next connection to the remote mailbox, it will be automatically deleted from the remote mailbox.

If you are using the POP3 protocol, messages marked to be deleted are removed only after you have closed the connection to the remote mailbox.

Undeleting e-mail messages when offline

To cancel deleting an e-mail from both the phone and server, scroll to an e-mail that has been marked to be deleted during the next connection () and select **Options**→ *Undelete*.

Disconnecting from mailbox

When you are online, select **Options**→ *Disconnect* to end the data call or GPRS connection to the remote mailbox.



Outbox

Outbox is a temporary storage place for messages that are waiting to be sent.

Status of the messages in Outbox:

- *Sending* - A connection is being made and the message is being sent.

- *Waiting / Queued* - For example, if there are two similar types of messages in Outbox, one of them is waiting until the first one is sent.
- *Resend at (time)* - Sending has failed. The phone will try to send the message again after a time-out period. Press *Send* if you want to restart the sending immediately.
- *Deferred* - You can set documents to be 'on hold' while they are in Outbox. Scroll to a message that is being sent and select **Options**→ *Defer sending*.
- *Failed* - The maximum number of sending attempts has been reached. If you were trying to send a text message, open the message and check that the Sending settings are correct.

Viewing messages on a SIM card

Before you can view SIM messages, you need to copy them to a folder in your phone. [See "Actions common to all applications" on page 12.](#)



Cell broadcast (Network Service)

↩ In the Messaging main view, select **Options**→ *Cell broadcast*.

▶ Options in Cell broadcast: *Open, Subscribe / Unsubscribe, Hotmark / Remove hotmark, Topic, Settings, Help, and Exit*.

You may be able to receive messages on various topics, such as weather or traffic conditions from your service provider. For available topics and relevant topic numbers, contact your service provider. In the main view you can see:

- the status of the topic:  - for new, subscribed messages and  - for new, unsubscribed messages.
- the topic number, topic name, and whether it has been flagged () for follow-up. You will be notified when messages belonging to a flagged topic have arrived.

A packet data (GPRS) connection may prevent cell broadcast reception. Contact your network operator for the correct GPRS settings.



Service command editor

Select **Messaging** → **Options** → **Service command**. Key in and send service requests (also known as USSD commands) such as activation commands, for network services, to your service provider.

Messaging settings

Settings for text messages

Go to **Messaging** and select **Options** → **Settings** → **Text message** to open the following list of settings:

- **Message centres** - Lists all the message centres that have been defined.
 - **Msg. centre in use** (Message centre in use) - Defines which message centre is used for delivering text messages and smart messages such as picture messages.
 - **Receive report** (delivery report) - When this network service is set to **Yes**, the status of the sent message (**Pending**, **Failed**, **Delivered**) is shown in the Reports (Network Service). Receiving a delivery report of a multimedia message that has been sent to an e-mail address might not be possible.
 - **Message validity** - If the recipient of a message cannot be reached within the validity period, the message is removed from the message service centre. Note that the network must support this feature. **Maximum time** is the maximum amount of time allowed by the network.
 - **Message sent as** - The options are **Text**, **Fax**, **Paging**, and **E-mail**. For further information, contact your network operator.
-  **Tip:** Change this option only if you are sure that your message centre is able to convert text messages into these other formats.
- **Preferred connection** - You can send text messages via the normal GSM network or via GPRS, if supported by the network.

 Options when editing message centre settings: **New msg. centre**, **Edit**, **Delete**, **Help**, and **Exit**.

- *Reply via same ctr.* (network service) - By setting this option to *Yes*, if the recipient replies to your message, the return message is sent using the same message service centre number. Note that this may not work between all operators.

Settings for multimedia messages

Go to **Messaging** and select **Options**→ **Settings**→ **Multimedia message** to open the following list of settings:

- *Access point in use (Must be defined)* - Select which access point is used as the preferred connection for the multimedia message centre. [See "Settings needed for multimedia messaging" on page 50.](#)

If you receive multimedia message settings in a smart message and save them, the received settings are automatically used for the Access point. [See "Receiving smart messages" on page 51.](#)

- *Multimedia reception* - Select:
 - *Only in home net.* - If you want to receive multimedia messages only when you are in your home network. When you are outside your home network, multimedia message reception is turned off.
 - *Always on* - If you always want to receive multimedia messages.
 - *Off* - If you do not want to receive multimedia messages or advertisements at all.



Tip: If the settings *Only in home net.* or *Always on* have been selected, your phone can make an active data call or GPRS connection without your knowledge

- *On receiving msg.* - Select:
 - *Retr. immediately* - If you want the phone to try to retrieve multimedia messages instantly. If there are messages with Deferred status, they will be retrieved as well.
 - *Defer retrieval* - If you want the multimedia messaging centre to save the message to be retrieved later. When you want to retrieve the message, set *On receiving msg.* to *Retr. immediately.*

- **Reject message** - If you want to reject multimedia messages. The multimedia message centre will delete the messages.
- **Allow anon. messages** - Select *No*, if you want to reject messages coming from an anonymous sender.
- **Receive adverts** - Define whether you want to allow reception of multimedia message advertisements or not.
- **Reports** - Set to *Yes*, if you want the status of the sent message (*Pending, Failed, Delivered*) to be shown in the Reports.
- **Deny report sending** - Choose *Yes*, if you do not want your phone to send delivery reports of received multimedia messages.
- **Message validity** (Network Service) - If the recipient of a message cannot be reached within the validity period, the message is removed from the multimedia message centre. **Maximum time** is the maximum amount of time allowed by the network.
- **Image size** - Define the size of the image in a multimedia message. The options are: *Small* (max. of 160*120 pixels) and *Large* (max. 640*480 pixels).
- **Default speaker** - Choose *Loudspeaker* or *Handset*, depending on whether you want the sounds in a multimedia message to be played through the loudspeaker or the earpiece.

Settings for e-mail

Go to **Messaging** and select **Options**→ **Settings**→ **E-mail**.

Open **Mailbox in use** to select which mailbox you want to use.

Settings for Mailboxes

Select **Mailboxes** to open a list of mailboxes that have been defined. If no mailboxes have been defined, you will be prompted to do so. The following list of settings is shown (this information is available from your e-mail service provider):

- **Mailbox name** - Write a descriptive name for the mailbox.
- **Access point in use (Must be defined)** - The Internet Access Point (IAP) used for the mailbox. Choose an IAP from the list. [See "Connection settings" on page 66.](#)

Options when editing e-mail settings: **Editing options, New mailbox, Delete, Help, and Exit.**

- *My e-mail address (Must be defined)* - Write the e-mail address given to you by your service provider. The address must contain the @ character. Replies to your messages are sent to this address.
- *Outgoing mail server: (Must be defined)* - Write the IP address or host name of the computer that sends your e-mail.
- *Send message (Network Service)* - Define how e-mail is sent from your phone.
Immediately - A connection to the mailbox is started immediately after you have selected *Send*. *During next conn.* - E-mail is sent when you connect to your remote mailbox the next time.
- *Send copy to self* - Select *Yes* to save a copy of the e-mail to your remote mailbox and to the address defined in *My e-mail address*.
- *Include signature* - Select *Yes* if you want to attach a signature to your e-mail messages and to start to write or edit a signature text.
- *User name:* - Write your user name, given to you by your service provider.
- *Password:* - Write your password. If you leave this field blank, you will be prompted for the password when you try to connect to your remote mailbox.
- *Incoming mail server: (Must be defined)* - The IP address or host name of the computer that receives your e-mail.
- *Mailbox type:* - Defines the e-mail protocol your remote mailbox service provider recommends. The options are *POP3* and *IMAP4*. This setting can be selected only once and cannot be changed if you have saved or exited from the mailbox settings.
- *Security* - Used with the POP3, IMAP4, and SMTP protocols to secure the connection to the remote mailbox.
- *APOPsecure login* - Used with the POP3 protocol to encrypt the sending of passwords to the remote e-mail server. Not shown if IMAP4 is selected for *Mailbox type*:
- *Retrieve attachment* (not shown if the e-mail protocol is set to POP3) - To retrieve e-mail with or without attachments.
- *Retrieve headers* - To limit the number of e-mail headers you want to retrieve to your phone. The options are *All* and *User defined*. Used with the IMAP4 protocol only.

Settings for service messages

When you go to **Messaging** and select **Options**→**Settings**→**Service message**, the following list of settings opens:

- **Service messages** - Choose whether or not you want to allow reception of service messages.
- **Authentic. needed** - Choose if you want to receive service messages only from authorised sources.

Settings for Cell broadcast (Network Service)

Check with your service provider whether Cell broadcast is available and what the available topics and related topic numbers are. Go to **Messaging**→**Options**→**Settings**→**Cell broadcast** to change the settings:

- **Reception** - **On** or **Off**.
- **Language** - **All** allows you to receive cell broadcast messages in every possible language. **Selected** allows you to choose in which languages you wish to receive cell broadcast messages. If the language you prefer could not be found in the list, select **Other**.
- **Topic detection** - If you receive a message that does not belong to any of the existing topics, **Topic detection**→**On** allows you to save the topic number automatically. The topic number is saved to the topic list and shown without a name. Choose **Off** if you do not want to save new topic numbers automatically.


Settings for the Other folder

Go to **Messaging** and select **Options**→**Settings**→**Other** to open the following list of settings:

- **Save sent messages** - Choose if you want to save a copy of every text message, multimedia message, or e-mail that you have sent to the Sent items folder.

- *No. of saved msgs.* - Define how many sent messages will be saved to the Sent items folder at a time. The default limit is 20 messages. When the limit is reached, the oldest message is deleted.
- *Memory in use* - Define the memory store. Choices are phone's memory or memory card, if one is used.

Tools



Settings

Changing general settings

- 1 Scroll to a setting group and press  to open it.
- 2 Scroll to a setting you want to change and press  to:
 - switch between options if there are only two (On/Off),
 - open a list of options or an editor,
 - open a slider view and press  or  to increase or decrease the value respectively.

 Go to [Menu](#) → [Settings](#).

See Fig. 13, p. 64. You may be able to receive some settings from your service provider in a short message. [See "Receiving smart messages" on page 51.](#)



Phone settings

General

- *Phone language* - You can change the language for the display texts in your phone. This change may also affect the format used for date and time and the separators used, for example, in calculations. If you select *Automatic*, the phone selects the language according to the information on your SIM card. After you have changed the display text language, you must restart the phone.

Changing the settings for *Phone language* or *Writing language* affects every application in your phone and the change remains effective until you change these settings again.

- *Writing language* - You can change the writing language of your phone. Changing the language affects:



Fig. 13 The Settings main view.

- the characters available when you press any key ( - )
- the predictive text dictionary used
- the special characters that are available when you press the  and  keys.
- **Dictionary** - To set predictive text input *On* or *Off* for all editors in the phone. Select a language for entering predictive text from the list available. You can also change this setting when you are in an editor. Press  and select **Dictionary** → **Dictionary on** or **Off**.
- **Welcome note or logo** - The welcome note or logo is displayed briefly each time you switch on the phone. Select **Default** if you want to use the default image or animation. Select **Text** to write a welcome note (max. 50 letters). Select **Image** to select a photo or picture from the Gallery.
- **Orig. phone settings** - You can reset some of the settings to their original values. To do this, you need the lock code. See "[Security](#)" on page 71. After resetting the settings, the phone may take a longer time to power on. All documents and files that you have created are left as they are.

Standby mode

- **Left selection key** and **Right selection key** - You can change the shortcuts that appear over the left  and right  selection keys in standby mode. In addition to the applications, you can have the shortcut point to a function, for example, [New message](#).

You can only have shortcuts to pre-installed applications and functions.

Display

- **Screen saver timeout** - The screen saver is activated when the screen saver time-out period is over. When the screen saver is active, the display is cleared and you can see the screen saver bar.
 - To deactivate the screen saver press any key.



Call settings

Send my caller ID (Network Service)

- This allows you to set your phone number to be displayed (*Yes*) or hidden (*No*) from the person to whom you are calling. Or, the value may be set by your network operator or service provider when you make a subscription.

Call waiting (Network Service)

- The network will notify you of a new incoming call while you have a call in progress. Select *Activate* to request the network to activate call waiting, *Cancel* to request the network to deactivate call waiting, or *Check status* to check if the function is active or not.

Automatic redial

- When this setting is activated, your phone will make a maximum of ten attempts to connect the call after an unsuccessful call attempt. Press  to stop automatic redialling.

Summary after call

- Activate this setting if you want the phone to briefly display the approximate duration of the last call.

Speed dialling

- Select *On* and the numbers assigned to the speed dialling keys ( - ) can be dialled by pressing and holding the key. [See "Assigning speed dialling keys" on page 25.](#)

Anykey answer

- Select *On*, and you can answer an incoming call by briefly pressing any key, except , , and .

Line in use (Network Service)

- This setting is shown only if the SIM card supports two subscriber numbers, that is, two phone lines. Select which phone line (*Line 1* or *Line 2*) you want to use for making calls and sending short messages. Calls on both lines can be answered irrespective of the selected line.

You will not be able to make calls if you select *Line 2* and have not subscribed to this network service.

To prevent line selection, select *Line change* → *Disable* if supported by your SIM card. To change this setting, you need the PIN2 code.



Connection settings

Access points

Here you can see a short explanation for every setting that may be needed for different data connections and access points. If you have not yet used your phone to make a WAP connection, you may need to contact your service provider for assistance with the first-time connection or visit www.nokia.com/phonesettings.

Many service providers will require you to use an IAP for your default access point. Other service providers allow you to use a WAP access point. Contact your service provider for more information.

Start to fill in the settings from the top because depending on what data connection you select (*Data bearer*) only certain setting fields are available.

- *Connection name* - Give a descriptive name for the connection.
- *Data bearer* - The options are *GPRS* or *Data call*. Depending on what data connection you select, only certain setting fields are available. Fill in all fields marked with **Must be defined**, or with an asterisk. Other fields can be left empty, unless you have been instructed otherwise by your service provider.

To be able to use a data connection, the network operator or service provider must support this feature, and if necessary, activate it for your SIM card.

- *Access point name* (for packet data only) - The access point name is needed to establish a connection to the GPRS network. You obtain the access point name from your network operator or service provider.
- *Dial-up number* (for Data call only) - The modem telephone number of the access point.
- *User name* - Write a user name if required by the service provider. The user name may be needed to make a data connection, and is usually provided by the service provider. The user name is often case-sensitive.
- *Prompt password* - If you must key in a new password every time you log onto a server, or if you do not want to save your password to the phone, choose *Yes*.
- *Password* - A password may be needed to make a data connection, and is usually provided by the service provider. The password is often case-sensitive. When you are writing the password, the characters you enter are shown briefly and then changed to asterisks (*). The easiest way to enter numbers is to press and hold the digit you want to enter, and then continue entering letters.
- *Authentication* - *Normal* / *Secure*.
- *Homepage* - Depending on what you are setting up, write either:
 - the service address, or
 - the address of the multimedia messaging centre.
- *Data call type* (for Data call only) - *Analogue*, *ISDN v.110*, or *ISDN v.120* defines whether the phone uses an analogue or digital connection. This setting depends on both your GSM network operator and Internet Service Provider (ISP), because some GSM networks do not support certain types of ISDN connections. For details, contact your ISP. If ISDN connections are available, they establish connections more quickly than analogue methods.
- *Maximum data speed* (for Data call only) - The options are *Automatic* / 9600 / 14400 / 19200 / 28800 / 38400 / 43200, depending on what you have chosen in *Data call type*. This option allows you to limit the maximum connection speed when GSM data is used. Higher data rates may cost more, depending on the service provider.

The speeds above represent the maximum speed at which your connection will operate. During the connection, the operating speed may be less, depending on network conditions.

Options→ Advanced settings

- *Phone IP address* - The IP address of your phone.
- *Primary name server* - The IP address of the primary DNS server.
- *Second. name server* - The IP address of the secondary DNS server.
- *Proxy serv. address* - The IP address of the proxy server.
- *Proxy port number* - The port number of the proxy server.

If you need to enter these settings, contact your Internet service provider.

The following settings are shown if you have selected data call as the connection type:

- *Use callback* - This option allows a server to call you back once you have made the initial call. Contact your service provider to subscribe to this service.
The phone expects the callback call to use the same data call settings that were used in the callback-requesting call. The network must support that type of call in both directions, to and from the phone.
- *Callback type* - The options are *Use server no.* / *Use other no.*. Ask your service provider for the correct setting to use; it will depend on the service provider's configuration.
- *Callback number* - Key in your phone's data phone number which the dial back server uses. Usually, this number is the data call phone number of your phone.
- *Use PPP compression* - When set to *Yes*, this option speeds up the data transfer, if supported by the remote PPP server. If you have problems with establishing a connection, try setting this to *No*. Contact your service provider for guidance.
- *Use login script* - The options are *Yes* / *No*.
- *Login script* - Insert the login script.
- *Modem initialisation* (Modem initialisation string) - Controls your phone using modem AT commands. If required, enter characters specified by your service provider or Internet service provider.

GPRS

The GPRS settings affect all access points using a packet data connection.

GPRS connection - If you select *When available* and you are in a network that supports packet data, the phone registers to the GPRS network and sending short messages will be done via GPRS. Also, starting an active packet data connection, for example, to send and receive e-mail, is quicker. If you select *When needed*, the phone will use a packet data connection only if you start an application or action that needs it. The GPRS connection can be closed after it is not used by any application.

If there is no GPRS coverage and you have chosen *When available*, the phone will periodically try to establish a packet data connection.

Access point - The access point name is needed when you want to use your phone as a packet data modem to your computer.

↩ Go to *Settings* →
Connection → *GPRS*.

Data call

The *Data call* settings affect all access points using a GSM data call.

Online time - If there are no actions the data call is dropped automatically after a time-out period. The options are *User defined*, in which case you enter a time, or *Unlimited*.

↩ Go to *Settings* →
Connection → *Data call*.



Date and time

The *Date and time* settings allow you to define the date and time used in your phone, as well as change the date and time format and separators.

- *Clock type* → *Analogue* or *Digital* - To change the clock shown in standby mode. [See "Clock" on page 90.](#)
- *Auto time update* - To allow the network to update time, date, and time zone information to your phone (Network Service). For the *Auto time update* setting to take effect, the phone needs to be restarted. Check any alarms as these may be affected by *Auto time update*.

- *Clock alarm tone* - To change the tone played when the clock alarm time is reached.
- *GMT offset* - To change the time zone for the clock time.
- *Daylight-saving* - To set daylight saving time on or off.



Call barring (Network Service)

Call barring allows you to restrict the making and receiving of calls with your phone. For this function, you need the barring password, which you can obtain from your service provider.

- 1 Scroll to one of the barring options.
 - 2 Select **Options**→ *Activate* to request the network to set call restriction on, *Cancel* to set the selected call restriction off, or *Check status* to check if the calls are barred or not.
- Select **Options**→ *Edit barrings passw.* to change the barring password.
 - Select **Options**→ *Cancel all barrings* to cancel all active call barrings.

When calls are barred, calls still may be possible to certain official emergency numbers.



Network

Operator selection

- Choose *Automatic* to set the phone to automatically search for and select one of the cellular networks available in your area.
- Choose *Manual*, if you want to select the desired network manually from a list of networks. If the connection to the manually selected network is lost, the phone will sound an error tone and ask you to select a network again. The selected network must have a roaming agreement with your home network, that is, the operator whose SIM card is in your phone.

Cell info display

- Select *On* to set the phone to indicate when it is used in a cellular network based on Micro Cellular Network (MCN) technology and to activate cell info reception (Network Service).



Enhancement settings

Scroll to an enhancement folder and open the settings:

- Select *Default profile* to select the profile you want to activate each time you connect a certain enhancement to your phone. [See "Changing the profile" on page 79.](#)
- Select *Automatic answer* to set the phone to answer an incoming call automatically after five seconds time when you connect a certain enhancement to your phone. If the *Incoming call alert* is set to *Beep once* or *Silent*, automatic answer cannot be used, and you must answer the phone manually.



Security

Phone and SIM

Explanations for the different security codes that may be needed:

- **PIN code (4 to 8 digits)** - The PIN (Personal Identification Number) code protects your SIM card against unauthorised use. The PIN code is usually supplied with the SIM card. After three consecutive incorrect PIN code entries, the PIN code is blocked. If the PIN code is blocked, you need to unblock the PIN code before you can use the SIM card again. See the information about the PUK code.
- **PIN2 code (4 to 8 digits)** - The PIN2 code, supplied with some SIM cards, is required to access some functions.
- **Lock code (5 digits)** - The lock code can be used to lock the phone and keypad to avoid unauthorised use.

The factory setting for the lock code is **12345**. To avoid unauthorised use of your phone, change the lock code. Keep the new code secret and in a safe place separate from your phone.

- **PUK and PUK2 codes (8 digits)** - The PUK (Personal Unlocking Key) code is required to change a blocked PIN code. The PUK2 code is required to change a blocked PIN2 code. If the codes are not supplied with the SIM card, contact the operator whose SIM card is in your phone for the codes.

You can change the following codes: lock code, PIN code, and PIN2 code. These codes can only include the numbers from **0** to **9**.

Avoid using access codes similar to emergency numbers, such as 112, to prevent accidental dialling of the emergency number.

PIN code request - When the PIN code request is active, the code is requested each time the phone is switched on. Note that deactivating the PIN code request may not be allowed by some SIM cards.

PIN code / PIN2 code / Lock code - Open this setting if you want to change the code.

Autolock period - You can set an autolock period, a time-out after which the phone is automatically locked and can be used only if the correct lock code is entered. Key in a number for the time-out in minutes or select *None* to turn off the autolock period.

- To unlock the phone, key in the lock code.

When the device is locked, calls still may be possible to the official emergency number programmed into your device.

Lock if SIM changed - Select *Yes* if you want the phone to prompt for the lock code when an unknown, new SIM card is inserted into your phone. The phone maintains a list of SIM cards that are recognised as the owner's cards.

Fixed dialling - You can restrict your outgoing calls to selected phone numbers, if supported by your SIM card. You need the PIN2 code for this function. When this function is active, you can only call those phone numbers that are included in the fixed dialling list or which begin with the same digit(s) as a phone number on the list.

- Press  to set **Fixed dialling** on.

When fixed dialling is activated, calls still may be possible to the official emergency number programmed into your device.

- To add new numbers to the Fixed dialling list, select **Options** → **New contact** or **Add from Contacts**.

Closed user group (Network Service) - You can specify a group of people to whom you can call and who can call you. For more information, contact your network operator or service provider. Select: **Default** to activate the default group agreed on with the network operator, **On** if you want to use another group (you need to know the group index number), or **Off**.

When calls are limited to closed user groups, calls still may be possible to the official emergency number programmed into your device.

Confirm SIM services (Network Service) - To set the phone to display confirmation messages when you are using a SIM card service.

Certif. management

In the Certificate management main view, you can see a list of authority certificates that have been stored in your phone. Press  to see a list of personal certificates, if available.

Authority certificates are used by some browser services, such as banking services, for checking signatures or server certificates or other authority certificates.

Server certificates are used to improve security in the connection between the phone and the gateway. The phone receives the server certificate from the service provider before the connection is established and its validity is checked using the authority certificates saved in the phone. Server certificates are not saved.

Options in the Fixed dialling view: **Open**, **Call**, **Activ. fixed dialling** / **Deact. fixed dialling**, **New contact**, **Edit**, **Delete**, **Add to Contacts**, **Add from Contacts**, **Find**, **Mark/Unmark**, **Help**, and **Exit**.

Options in the certificate management main view: **Certificate details**, **Delete**, **Trust settings**, **Mark/Unmark**, **Help**, and **Exit**.

Server certificates may be needed when you, for example:

- want to connect to an online bank or another site or remote server for actions that involve transferring confidential information, or
- want to decrease the risk of viruses or other malicious software and be sure of the authenticity of software when downloading and installing software.



Important: Note that even if the use of certificates makes the risks involved in remote connections and software installation considerably smaller, they must be used correctly in order to benefit from increased security. The existence of a certificate does not offer any protection by itself; the certificate manager must contain correct, authentic, or trusted certificates for increased security to be available. Certificates have a restricted lifetime. If *Expired certificate* or *Certificate not valid yet* is shown even if the certificate should be valid, check that the current date and time in your device are correct.

Before changing any certificate settings, you must make sure that you really trust the owner of the certificate and that the certificate really belongs to the listed owner.

Changing the trust settings of an authority certificate

- Scroll to an authority certificate and select **Options** → *Trust settings*. Depending on the certificate, a list of the applications that can use the selected certificate is shown. For example:
 - Application manager* / *Yes* - The certificate is able to certify the origin of new software.
 - Internet* / *Yes* - The certificate is able to certify e-mail and imaging servers.

Device manager

Device manager allows a third party, such as your service provider, to assist you directly with phone settings. To allow device management, your phone must establish a connection and synchronise with the third party's server. You can start the synchronisation session from your phone, and you can accept or reject server-initiated synchronisation attempts.

 Go to **Menu** →
Tools → **Device manager**

This feature is operator dependent and may not be available on all phones. Contact your service provider for information and availability.

A device manager profile must be defined before you can connect to a server. The third party who is assisting you can help define the profile settings:

Server name – Display name of the server.

Server ID – Remote device manager server ID.

Server password – Password used in server alerts. Enter the password that must be provided by the device manager server when synchronising with your phone.

Access point – Internet access point your phone uses to establish the server connection. Choose from the list of access points defined in your phone.

Host address – Device management server URL.

Port – Device management server port.

User name – Your user name for this profile.

Password – Your password for this profile.

Server will start configuration. Continue? – Device management allowed on this server. Select **Yes** or **No**.

Auto-accept all reqs. – Automatic or approved device management on this server. Select **Yes** to allow synchronisation without your verification, or select **No** to verify each synchronisation attempt.

Options in the Device manager main view: [Connect](#), [New profile](#), [Edit profile](#), [Delete profile](#), [Enable config.](#) | [Disable config.](#), [View log](#), [Help](#), and [Exit](#).



File manager

In File manager you can browse, open, and manage files and folders in the phone memory or on the memory card, if you use one.

Go to [Menu](#) → [Tools](#) → [File manager](#)

Options in the File manager main view:

Open, Send, Delete, Move to folder, Copy to folder, New folder, Mark/Unmark, Rename, Find, View details, Memory details, Help, and Exit.

Open File manager to see a list of the folders in the phone memory. Press  to see the folders on the memory card, if you use one.

You can browse, open, and create folders, mark, copy and move items to folders. [See "Actions common to all applications" on page 12.](#)

Viewing memory consumption

If you have a memory card installed on your phone, you will have a choice of two memory views, one for the phone memory and one for the memory card.

Press  or  to move from one memory tab to another.

- To check memory consumption of the current memory select **Options** → *Memory details*.

The phone calculates the approximate amount of free memory for storing data and installing new applications.

In the memory views, you can view the memory consumption of the different data groups: *Calendar, Contacts, Documents, Messages, Images, Sound files, Video clips, Applications, Mem. in use, and Free memory.*

If the phone memory is getting low, remove some files, or move them to the memory card. [See "Troubleshooting" on page 120.](#)



Voice commands

You can use Voice commands to start applications and profiles, and to dial numbers from Contacts, without having to look at your phone's display. You record a word, or words, (voice command) and then pronounce this voice command to open an application, activate a profile, or dial a number.

You can have only one voice command per item.

 **Go to Menu** → **Tools** → **Voice commands.**

Any spoken word(s) can be a voice command.

- When recording, hold the phone at a short distance away from your mouth. After the starting tone, clearly pronounce the word, or words, you want to record as a voice command.

Before using voice tags, note that:

- Voice tags are not language-dependent. They are dependent on the speaker's voice.
- You must say the name exactly as you said it when you recorded it.
- Voice tags are sensitive to background noise. Record voice tags and use them in a quiet environment.
- Very short names are not accepted. Use long names and avoid similar names for different numbers.



Note: Using voice tags may be difficult in a noisy environment or during an emergency, so you should not rely solely upon voice dialling in all circumstances.

Options in the Voice commands main view: [Add voice command](#), [Open](#), [New application](#), [Playback](#), [Change](#), [Delete](#), [Delete all](#), [Help](#), and [Exit](#).

Adding a voice command to an application

- 1 In the Voice commands main view, scroll to the application that you want to add a voice command to, and select **Options** → [Add voice command](#).
To add a voice command to a profile, the Profiles folder must be opened and a specific profile selected.
- 2 The text *Press 'Start', then speak after tone* is displayed.
 - Press **Start** to record a voice command. The phone sounds a starting tone and the note *Speak now* is displayed.
- 3 Pronounce the voice command. The phone will stop recording after approximately 5 seconds.
- 4 After recording, the phone plays the recorded command and the note *Playing voice command* is displayed. If you do not want to save the recording, press **Quit**.
- 5 When the voice command has been successfully saved, the note *Voice command saved* is displayed and a beep sounds. A symbol  can be seen next to the application.

Adding an application to the list

Assign voice commands to other applications that are not listed in the Voice commands main view.

- 1 In the Voice commands main view, select **Options**→ *New application*.
- 2 Available applications are displayed. Scroll to the application that you want to add and press **Select**.
- 3 Add a voice command to the new application. [See "Adding a voice command to an application" on page 77.](#)

Starting an application using a voice command

- 1 In standby mode, press and hold . A short tone is played and the note *Speak now* is displayed.
- 2 When you are starting an application by saying a voice command, hold the phone at a short distance away from your mouth and pronounce the voice command clearly.
- 3 The phone plays the original voice command and starts the application. If the phone plays the wrong voice command, press **Retry**.

Replaying, erasing, or changing a voice command

To replay, erase, or change a voice command, scroll to the item that has a voice command (indicated by ) , select **Options**, and then either:

- *Playback* - To listen to the voice command again.
- *Delete* - To erase the voice command.
- *Change* - To record a new voice command. Press **Start** to record.

Personalising your phone



Profiles

In Profiles, you can adjust and customise the phone tones for different events, environments, or caller groups. You can see the currently selected profile at the top of the display in standby mode. If the General profile is in use, only the current date is shown.

Changing the profile

- 1 Go to [Menu](#) → [Profiles](#). A list of profiles opens.
 - 2 In the Profiles list, scroll to a profile and select [Options](#) → [Activate](#).
-  **Shortcut!** To change the profile, press  in standby mode, scroll to the profile you want to activate and press **OK**.

Customising profiles

- 1 To modify a profile, scroll to the profile in the Profiles list and select [Options](#) → [Personalise](#). To create a new profile, select [Options](#) → [Create new](#). A list of profile settings opens.
- 2 Scroll to the setting you want to change and press  to open the choices:
 - [Ringing tone](#) - To set the ringing tone for voice calls, choose a ringing tone from the list. Press any key to stop the sound. If a memory card is used, tones stored on it have the  icon next to the tone name. Ringing tones use shared memory. [See "Shared memory" on page 14](#). You can also change ringing tones in Contacts. [See "Adding a ringing tone for a contact card or group" on page 23](#).

 Go to [Menu](#) → [Profiles](#).

 Options in the Profiles main view: [Activate](#), [Personalise](#), [Create new](#), [Delete profile](#), [Tone downloads](#), [Help](#), and [Exit](#).



Tip! When you scroll through the list, you can stop on a tone to listen to it before you make your selection.

- *Ringin*g type - When *Ascending* is selected, the ringing volume starts from level one and increases level by level to the set volume level.
- *Ringin*g volume - To set the volume level for the ringing and message alert tones.
- *Message alert tone* - To set the tone for messages.
- *Chat alert tone* - To set the tone for instant messages.
- *Vibrating alert* - To set the phone to vibrate at incoming voice calls and messages.
- *Keypad tones* - To set the volume level for keypad tones.
- *Warning tones* - The phone sounds a warning tone, for example, when the battery is running low of power.
- *Alert for* - To set the phone to ring only upon calls from phone numbers that belong to a selected contact group. Phone calls coming from people outside the selected group will have a silent alert. The choices are *All calls* / (list of contact groups, if you have created them). [See "Creating contact groups" on page 25.](#)
- *Availability* - Select *Available*, *Busy*, or *Not available*. [See "Presence settings" on page 29.](#)
- *User availab. alerts* - Key in a message to display your current presence status. [See "Presence settings" on page 29.](#)
- *Profile name* - You can rename a profile and give it any name you want. The General profile cannot be renamed.



Themes

➔ Go to **Menu**→
Themes.

You can change the look of your phone's display by activating a theme. A theme can include the idle screen wallpaper, colour palette, screen saver, and icons and background image in 'Go to'. Edit a theme for more detailed personalisation.

When you open **Themes** you will see a list of the available themes. The currently active theme is indicated by a check mark. Press  to see the themes on the memory card, if you use one.

- To preview a theme, scroll to the theme and select **Options**→ *Preview* to view the theme. Press  to activate the theme. You can activate the theme without previewing it by selecting **Options**→ *Apply* from the main view.

Editing themes

Group together elements from other themes, or images from the Gallery to personalise themes further.

- 1 Scroll to a theme, select **Options**→ *Edit*, and select:
 - *Wallpaper* - To select an image from one of the available themes, or select your own image from the Gallery, to use as a background image in standby mode.
 - *Colour palette* - To change the colour palette used on the display.
 - *Screen saver* - To select what is shown on the screen saver bar: the time and date or a text you have written yourself. The location and background colour of the screen saver bar changes in one minute intervals. Also, the screen saver changes to indicate the number of new messages or missed calls. You can set the time that elapses before the screen saver is activated. [See "Phone settings" on page 63.](#)
 - *Icons* - To select a different icon set from any one of the themes. All pre-installed themes have the same icon set.
 - *Image in 'Go to'* - To select an image from one of the available themes, or select your own image from the Gallery, to use as a background image in Go to.
- 2 Scroll to the element to be edited and select **Options**→ *Change*.
- 3 Select **Options**→ *Set* to select the current setting. You can also preview the selected element by selecting **Options**→ *Preview*. Note that you cannot preview all elements.

 Options in the Themes main view: *Preview, Apply, Edit, Copy to mem. card, Copy to phone mem., Theme downloads, Help, and Exit.*




Fig. 14 The Themes main view.

➡ Press **Go to** in standby mode or go to **Menu**→ **Go to**.

▶ Options in the Go to main view: *Open*, *Edit shortcut name*, *Shortcut icon*, *Delete shortcut*, *Move*, *List view / Grid view*, *Help*, and *Exit*.



Restoring themes

To restore the currently selected theme back to its original settings, select **Options**→ *Restore orig. theme* when editing a theme.

Go to

Use Go to for storing shortcuts, links to your favourite photos, video clips, notes, Recorder sound files, browser bookmarks, and saved browser pages.

The default shortcuts: - opens the Notes editor, - opens the Calendar to the current date, and - opens the Messaging Inbox.

Adding shortcuts

Shortcuts can be added only from pre-installed applications and functions. Not all applications have this functionality.

- 1 Open the application and scroll to the item that you want to add as a shortcut.
- 2 Select **Options**→ *Add to 'Go to'* and press **OK**.



Shortcut! A shortcut in Go to is automatically updated if you move the item it is pointing to, for example, from one folder to another.

Using shortcuts:

- **To open a shortcut**, scroll to the icon and press . The file is opened in the corresponding application.

- **To delete a shortcut**, scroll to the shortcut you want to remove and select **Options**→ *Delete shortcut*. Removing a shortcut does not affect the file it is referring to.
- **To change the shortcut name**, select **Options**→ *Edit shortcut name*. Write the new name. This change affects only the shortcut, not the file or item the shortcut refers to.



Fig. 15 The Go to main view.

Extras



Wallet

↩ Go to **Menu** →
Extras → **Wallet**.

Wallet provides you with a storage area for your personal information, such as credit and debit card numbers, addresses and other useful data, for example, user names and passwords.

The information stored in the wallet can be easily retrieved while browsing to automatically fill in online forms on browser pages, for example, when the service asks for credit card details. Data in the wallet is encrypted and protected with a wallet code that you define.

You can group wallet data into profiles that can be accessed, for example, for making purchases online.

Due to the nature of the wallet, it will automatically close after 5 minutes. Enter the wallet code to regain access to the contents. You can change this automatic time-out period, if required. [See "Wallet settings" on page 87.](#)




Fig. 16 The wallet main view.

Options in the wallet main view: **Open**, **Settings**, **Help**, and **Exit**.

Entering the wallet code

Each time you open the wallet you will be prompted for a wallet code.

When you open the wallet for the first time, you must create your own access code:

- 1 Enter a code of your choice (4 - 10 alphanumeric characters), and press **OK**.

- 2 You will be prompted to verify the code. Enter the same code and press **OK**. Do not give your wallet code to anyone else.

Enter the code that you have created and press **OK**.

If you enter the wallet code incorrectly on three consecutive occasions, the wallet application is blocked for five minutes. The block time increases if further incorrect wallet codes are entered.

If you forget your wallet code, you will have to reset the code, and you will lose all information stored in the wallet. [See "Resetting the wallet and wallet code" on page 88.](#)

Storing personal card details

- 1 Select the *Cards* category from the main wallet menu and press .
- 2 Select a type of card from the list and press 
 - *Payment cards* - Credit and debit cards.
 - *Loyalty cards* - Membership and store cards.
 - *Online acc. cards* - Personal user names and passwords to online services.
 - *Address cards* - Basic contact details for home/office.
 - *User info cards* - Customised personal preferences for online services.
- 3 Select **Options** → *Create new*. An empty form opens.
- 4 Fill in the fields and press **Done**.

You can also receive card information directly to the phone from a card issuer or service provider (if they offer this service). You will be notified which category the card belongs to. Either save or discard the card. You can view and rename a saved card, but you cannot edit it.

You can open, edit or delete the fields in the card. Any changes will be saved upon exiting.

Options when viewing or editing card details: [Delete](#), [Help](#), and [Exit](#).

Creating personal notes

Personal notes are a means of storing sensitive information, for example, a bank account number. You can access the data in a personal note from the browser. You can also send a note as a message.

- Select the [Personal notes](#) category from the main wallet menu and press .
- Select [Options](#) → [Create new](#). An empty note opens.
- Press  -  to start writing. Press  to clear characters. Press [Done](#) to save.

Creating a wallet profile

Once you have stored your personal details, you can combine them together into a wallet profile. Use a wallet profile to retrieve wallet data from different cards and categories to the browser.

- 1 Select the [Wallet profiles](#) category from the main wallet menu and press .
- 2 Select [Options](#) → [Create new](#). A new wallet profile form opens.
- 3 Fill in the fields as indicated below and press [Done](#).

Some of the fields must contain data selected from the wallet. You must save the data under the relevant category before creating a wallet profile, or the profile cannot be created.

- [Profile name](#) - Choose and enter a name for the profile.
- [Payment card](#) - Select a card from the Payment card category.
- [Loyalty card](#) - Select a card from the Loyalty card category.
- [Online access card](#) - Select a card from the Online acc. card category.
- [Shipping address](#) - Select an address from the Address card category.
- [Billing address](#) - By default this is the same as the Shipping address. If you require a different address, select one from the Address card category.
- [User info card](#) - Select a card from the User info card category.
- [Receive e-receipt](#) - Select a destination from the Address card category.

- *Deliver e-receipt* - Select *To phone*, *To e-mail*, or *To pho. & e-mail*.
- *RFID sending* - Set to *On* or *Off*. Defines whether, or not, your unique phone identification is sent with the wallet profile (for future development dependent on RFID-based ticketing).

Retrieving information from the wallet to your browser

When using online mobile services supporting the wallet functionality, you can upload the data stored in your wallet to automatically enter your details into an online form. For example, by uploading your payment card details you do not need to key in the card number and expiry date each time you need them (depending on the content being browsed). Also, you can retrieve your user name and password stored as an access card when connecting to a mobile service that requires authentication. [See "Purchasing an item" on page 106.](#)

Viewing ticket details

You can receive notifications of tickets purchased online via the browser. Received notifications are stored in the wallet. To view the notifications:

- 1 Select the *Tickets* category from the main wallet menu and press .
- 2 Select **Options**→ *View*.

 Options in the Tickets main view: *View*, *Delete*, *Rename*, *Mark/Unmark*, *Help*, and *Exit*.

Wallet settings

Select **Options**→ *Settings* from the main wallet menu:

- *Wallet code* - Change your wallet code. You will be prompted to enter the current code, create a new code, and verify the new code.
- *RFID* - Set the phone ID code, type, and sending options (for future development dependent on RFID-based ticketing).

- **Automatic close** - Change the automatic time-out period (1 - 60 minutes). After the time-out period has elapsed, the wallet code must be re-entered to gain access to the contents.

Resetting the wallet and wallet code

To reset both the contents of the wallet and the wallet code:

- 1 Key in *#7370925538# in standby mode.
- 2 Enter the phone's lock code, and press **OK**. See ["Security" on page 71](#).
- 3 You will be asked to confirm the erasing of data. Press **OK**.

When opening the wallet again, you must enter a new wallet code. See ["Entering the wallet code" on page 84](#).



Calculator

➔ Go to **Menu**→
Extras→ **Calculator**.

▶ Options in
Calculator: [Last result](#),
[Memory](#), [Clearscreen](#), [Help](#),
and [Exit](#).

- 1 Enter the first number of your calculation. If you make a mistake, press to erase it.
- 2 Scroll to an arithmetic function and press to select it.
- 3 Enter the second number.
- 4 To execute the calculation, scroll to and press .

Note: This calculator has limited accuracy and is designed for simple calculations.

- To add a decimal, press .
- Press and hold to clear the result of the previous calculation.
- Use and to view previous calculations and move in the sheet.



Converter

➔ Go to **Menu**→
Extras→ **Converter**.

In Converter, you can convert measures such as [Length](#) from one unit to another, for example, [Yards](#) to [Metres](#).

The Converter has limited accuracy and rounding errors may occur.

Converting units

To make currency conversion you must first set the exchange rate. See ["Setting a base currency and exchange rates" on page 89.](#)

- 1 Scroll to the *Type* field and press  to open a list of measures. Scroll to the measure you want to use and press **OK**.
- 2 Scroll to the first *Unit* field and press  to open a list of available units. Select the unit **from** which you want to convert and press **OK**.
- 3 Scroll to the next *Unit* field and select the unit **to** which you want to convert.
- 4 Scroll to the first *Amount* field and key in the value you want to convert. The other *Amount* field changes automatically to show the converted value.

Press  to add a decimal and press  for the +, - (for temperature), and E (exponent) symbols.

The conversion order changes if you write a value in the second *Amount* field. The result is shown in the first *Amount* field.

Setting a base currency and exchange rates

Before you can make currency conversions, you need to choose a base currency (usually your domestic currency) and add exchange rates.

The rate of the base currency is always 1. The base currency determines the conversion rates of the other currencies.

- 1 Select *Currency* as the measure type and select **Options**→ *Currency rates*. A list of currencies opens and you can see the current base currency at the top.
- 2 To change the base currency, scroll to the currency (usually your domestic currency), and select **Options**→ *Set as base curr.*

Options in Converter: *Conversion type*, *Currency rates* (not applicable to other units), *Help*, and *Exit*.

 **Tip:** When you change the base currency, all previously set exchange rates are set to **0** and you need to key in new rates.

- 3 Add exchange rates, scroll to the currency, and key in a new rate, that is, how many units of the currency equal one unit of the base currency you have selected.
- 4 After you have inserted all the required exchange rates, you can make currency conversions. See ["Converting units" on page 89.](#)



Notes

← Go to **Menu** →
Extras → **Notes**.

You can link notes to Go to and send them to other devices. Plain text files (TXT format) you receive can be saved to Notes.

- Press  -  to start to write. Press  to clear letters. Press **Done** to save.



Clock

← Go to **Menu** →
Extras → **Clock**.

Changing clock settings

Options in Clock:
[Set alarm](#), [Reset alarm](#),
[Remove alarm](#), [Settings](#),
[Help](#), and [Exit](#).

- To change the time or date, select **Options** → [Settings](#) in Clock.

Setting an alarm

- 1 To set a new alarm, select **Options** → [Set alarm](#).
 - 2 Enter the alarm time and press **OK**. When the alarm is active, the  indicator is shown.
- To cancel an alarm, go to clock and select **Options** → [Remove alarm](#).

Turning off the alarm

- Press **Stop** to turn off the alarm.
- Press any key or **Snooze** to stop the alarm for five minutes, after which it will resume. You can do this a maximum of five times.

If the alarm time is reached while the phone is switched off, the phone switches itself on and starts sounding the alarm tone. If you press **Stop**, the phone asks whether you want to activate the phone for calls. Press **No** to switch off the phone or **Yes** to make and receive calls. Do not press **Yes** when wireless phone use is prohibited or when it may cause interference or danger

Personalising the alarm tone

- 1 To personalise the alarm tone, select **Options**→ *Settings*.
- 2 Scroll to *Clock alarm tone* and press .
- 3 When you scroll through the list of tones, you can stop on a tone to listen to it before you make your selection. Press **Select** to select the current tone.



Recorder

The voice recorder allows you to record telephone conversations and voice memos. If you are recording a telephone conversation, both parties will hear a tone every five seconds during recording.

Recorded files are stored in the Gallery. [See "Gallery" on page 40.](#)

- Select **Options**→ *Record sound clip* and scroll to a function and press  to select it. Use:  - to record,  - to pause,  - to stop,  - to fast forward,  - to fast rewind, or  - to play an opened sound file.

Recorder cannot be used when a data call or a GPRS connection is active.

Games

- To start a game, scroll to the game icon and press . For instructions on how to play the game, select **Options**→ *Help*.

 Go to **Menu**→ **Extras**→ **Recorder**.

 Options in Recorder: *Record sound clip, Delete, Rename sound clip, Send, Go to Gallery, Settings, Add to 'Go to', Help, and Exit.*

 Go to **Menu**→ **Games**.

Chat (Network Service)

➔ Go to **Menu**→ **Chat**.

Chat allows you to converse with other people using instant messages, and join discussion forums (chat groups) with specific topics. Once you have registered with a chat service, you can log into the service provider's chat server. See Fig. 17, p. 92.

Check the availability of chat services, pricing, and tariffs with your network operator and/or service provider. Service providers will also give you instructions on how to use their services.

Options in the Chat main view: [Open](#), [Login](#), [Logout](#), [Settings](#), [Help](#), and [Exit](#).

Before using Chat

To access a chat service you need to save the settings for that service. You may receive the settings from the network operator or service provider that offers the service. [See "Receiving smart messages" on page 51.](#) You can also key in the settings manually. [See "Chat and Presence servers" on page 98.](#)

Connecting to a chat server

- 1 Go to **Menu**→ **Chat** to connect to a chat server. You can change the chat server to connect to. [See "Chat and Presence servers" on page 98.](#)




Fig. 17 The Chat main view.

- 2 Once the connection has been established, key in your user ID and password and press , or press [Cancel](#) to stay offline. When you are offline, your phone is not connected to the chat server and you cannot send or receive messages. To log in later, select [Options](#)→[Login](#).
You obtain the user ID and password from your service provider.

To log out, select [Options](#)→[Logout](#).

Modifying your chat settings

Select [Options](#)→[Settings](#)→[Chat settings](#).

- [Use screen name](#) - Select [Yes](#) to key in a nickname (max. 10 characters).
- [Chat presence](#) - To prevent others from seeing if you are online, select [Not active](#).
- [Allow messages from](#) - Select [All](#), [From chat contacts](#) or [None](#).
- [Allow invitations from](#) - Select [All](#), [From chat contacts](#) or [None](#).
- [Message speed](#) - Select the speed at which new messages are displayed.
- [Auto-reload availab.](#) - To choose how to update information about whether your chat contacts are online or offline. Select [Automatically](#) or [Manually](#).
- [Reload user availab.](#) - Select [For all contacts](#) or [For sel. contacts](#).

Joining and leaving a chat group

Go to the [Chat groups](#) view. A list of chat groups that you have saved or are currently joined to is shown. See Fig. 18, p. 93. The icon next to a group indicates what type it is:

-  - A group that you have created and are currently joined to.
-  - A group that you have created but are not currently joined to.
-  - A group that you have saved and are currently joined to.
-  - A group that you have saved but are not currently joined to.



Fig. 18 The Chat groups view.

Options in the Chat groups view: [Open](#), [Join group](#), [Create new group](#), [Leave chat group](#), [Chat group](#), [Search](#), [Settings](#), [Help](#), and [Exit](#).

-  - A group that you are currently joined to but have not saved.

To join a chat group: Scroll to a group on the list and press . To join a chat group not on the list but for which you know the group ID, select **Options** → [Join group](#). Key in the group ID and press .

You can scroll to a group, press **Options** → [Chat group](#) and then select: [Save group](#), [Delete](#), [View members](#) to see who are currently joined to the group, [Chat group details](#) to see the group ID, topic, members, editing rights in the group, and whether sending private messages is allowed in the group, and [Chat group settings](#) to view and edit the chat group's settings. See ["Editing chat group settings" on page 97](#).

To leave the chat group: Select **Options** → [Leave chat group](#).

Searching for chat groups and users

Go to the **Chat groups** view and select **Options** → [Search](#) → [Groups](#) or [Users](#).

- You can search for **Groups** by [Group name](#), [Topic](#), and [Members](#) (user ID). For groups that you have found you can select [New search](#), [Join](#) and [Save group](#).
- You can search for **Users** by [User's name](#), [User ID](#), [Phone number](#), and [E-mail address](#). For users that you have found you can select [New search](#), [Open conversation](#), [Add to Chat contact](#) to save the contact, [Send invitation](#), and [Add to blocked list](#) to block (or unblock) messages from the contact.

When the search result is displayed, you can select **Options** → [New search](#), [More results](#) from the same search, and [Previous results](#) to see your previous search result.

Chatting in a chat group

Once you have joined a chat group, you can view the messages that are exchanged in the group, and send your own messages.

- To send a message, write the message and press .
- To send a private message to a member (if allowed in the group), select **Options**→ *Send private msg.*, select the recipient, write the message, and press . To reply to a private message sent to you, select **Options**→ *Reply*.

To invite chat contacts who are online to join the chat group (if allowed in the group), select **Options**→ *Send invitation*, select the contacts you want to invite, write the invitation message, and press **Done**.

Recording messages

To record the messages that are exchanged in a chat group or during an individual conversation, select **Options**→ *Record convers.* Key in the name for the message file and press . To stop recording, select **Options**→ *Stop recording*.

The recorded message files are saved to Notes. [See "Notes" on page 90.](#)

Blocking messages

To prevent receiving messages from certain chat users, select **Options**→ *Blocking options* and then select:

- *Add to blocked list* - To block messages from the currently selected user.
- *Add ID to list manually* - Key in the user ID of the user and press .
- *View blocked list* - To see the users whose messages are blocked.
- *Unblock* - Select the user that you want to remove from the blocked list and press .

Starting and viewing individual conversations

Go to the **Conversations** view for a list of the chat users with whom you have an ongoing conversation. See Fig. 19, p. 95.

To start a new conversation, select **Options**→ *New conversation* and then select:

 Options while chatting: *Send, Send private msg., Reply, Send invitation, Leave chatgroup, Save group, Record convers./Stop recording, Help, and Exit.*



Fig. 19 The Conversations view.

Options in the Conversations view: *Send, Add to chat contact, Forward, Record convers./ Stop recording, Blocking options, End conversation, Help, and Exit.*

Icon:  next to a user indicates that you have received a new message from that user.

- *Select recipient* - To see a list of your saved chat contacts that are currently online. Scroll to the contact and press .
- *Enter user ID* - Key in the user ID and press . The user ID is provided by the service provider to those who register to the service.

To view an ongoing conversation, scroll to the user and press . To continue the conversation, write your message and press . To return to the conversations list without closing the conversation, press **Back**.

To close the conversation, select **Options** → *End conversation*.

Ongoing conversations are automatically closed when you exit Chat.

To save a user to your chat contacts, scroll to the user and select **Options** → *Add to Chat contact*.

To send automatic replies to incoming messages, select **Options** → *Set auto reply on*. Key in the text and press **Done**.

Chat contacts

Go to the **Chat contacts** view to see a list of your saved chat contacts.  is shown next to contacts that are currently online, and  for contacts that are offline.

To create a new contact, select **Options** → *New chat contact*. Fill in the *Name* and *User ID* fields and press **Done**.

You can scroll to a contact and press  to view contact details. Press **Options** and select:

- *Edit* - To edit the contact's details.
- *Open conversation* - To start a new conversation or continue an ongoing conversation with the contact.
- *Switch tracking on* - To be notified every time the chat contact goes online or offline.
- *Belongs to groups* - To see which groups the chat contact has joined.

- *Reload user availab.* - To update information about whether contacts are online or offline. This option is not available if you have set the *Auto-reload availab.* to *Automatically* in **Chat settings**.

Editing chat group settings

You can edit the settings for a chat group if you have created the group or if the creator of the group has given you editing rights. Go to the **Chat groups** view, scroll to the desired group and select **Options**→ *Chat group*→ *Chat group settings*. See "[Creating a new chat group](#)" on page 97.

Creating a new chat group

Go to the **Chat groups** view and select **Options**→ *Create new group*. Key in the settings for the group:

- *Group name*, *Group topic*, and a *Welcome note* that the participants see when they join the group.
- *Group size* - Maximum number of members allowed to join the group.
- *Allow search* - To define if others can find the chat group by searching.
- *Editing rights* - Scroll to the chat group members to whom you want to give editing rights and permission to invite contacts to join the group.
- *Group members* - See "[Restricting access to a chat group](#)" on page 97.
- *Banned* - Displays a list of banned users.
- *Allow private msgs.* - To allow or prevent private messaging between members.
- *Group ID* - Is created automatically and cannot be changed.

Restricting access to a chat group

You can make a chat group closed by creating a **Group members** list. Only the users on the list are allowed to join the group. Go to the **Chat groups** view, scroll to the group and select **Options**→ *Chat group*→ *Chat group settings*→ *Group members* → *Selected only*.

- To add a user to the list, select *Add* and *Chat contact* or *Enter user ID*.

Options in the Chat contacts view: *Open*, *Open conversation*, *Switch tracking on*, *Belongs to groups*, *New chat contact*, *Edit*, *Delete*, *Reload user availab.*, *Blocking options*, *Search*, *Settings*, *Help*, and *Exit*.

- To remove a user from the list, scroll to the user and select [Remove](#).
- To clear the list and allow all chat users to join the group again select [Remove all](#).

Chat and Presence servers

Select [Options](#)→ [Settings](#)→ [Server settings](#). You may receive the settings as a smart message from the service provider that offers the chat service.

- To change the chat or presence server you wish to connect to, select [Server in use](#).
- To change the Presence login type, select [Login type](#) and select [Automatic](#), [Aut. in home net](#), or [Manual](#).
- To change the Chat login type, select [Login type](#) and select [Automatic](#) or [Manual](#).
- To add a new server, select [Options](#)→ [New server](#). Key in or select the settings: [Server name](#) and [Access point in use](#) to connect to the server, [Web address](#) of the chat server, your [User ID](#) and login [Password](#). See "[Connection settings](#)" on page 66.



You obtain the user ID and password from your service provider when you register to the service. If you do not know your user ID or password, contact your service provider.

Memory card

For details on inserting a memory card into the phone, see the Getting Started guide. You can use it to store your multimedia files such as video clips and sound files, photos, messaging data, and to backup information from your phone's memory.

↩ Go to [Menu](#)→
[Extras](#)→ [Memory card](#).

Included with your Nokia 7610 phone is a Multimedia Memory Card (MMC) that may contain add-on applications from independent developers. These applications are designed by the developers to be compatible with your phone.



NO WARRANTY:

The applications provided on the MultiMediaCard (MMC) have been created and are owned by persons or entities that are not affiliated with or related to Nokia. Nokia does not own the copyrights and/or intellectual property rights to these third party applications. As such,

Nokia does not take responsibility for any end user support or the functionality of these applications, nor the information presented in the applications or these materials. Nokia does not provide any warranty for these applications.

YOU ACKNOWLEDGE THE SOFTWARE AND/OR APPLICATIONS (COLLECTIVELY, THE "SOFTWARE") ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND EXPRESS OR IMPLIED AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW NEITHER NOKIA NOR ITS AFFILIATES MAKE ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF TITLE, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR THAT THE SOFTWARE WILL NOT INFRINGE ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADEMARKS OR OTHER RIGHTS.

THERE IS NO WARRANTY BY NOKIA OR BY ITS AFFILIATES THAT ANY ASPECT OF THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT THE OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE. YOU ASSUME ALL RESPONSIBILITY AND RISK FOR THE SELECTION OF THE SOFTWARE TO ACHIEVE YOUR INTENDED RESULTS AND FOR THE INSTALLATION, USE AND RESULTS OBTAINED FROM IT. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL NOKIA, ITS EMPLOYEES OR AFFILIATES BE LIABLE FOR ANY LOST PROFITS, REVENUE, SALES, DATA, INFORMATION OR COSTS OF PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, PROPERTY DAMAGE, PERSONAL INJURY, INTERRUPTION OF BUSINESS, OR FOR ANY DIRECT, INDIRECT, INCIDENTAL, ECONOMIC, COVER, PUNITIVE, SPECIAL OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND WHETHER ARISING UNDER CONTRACT, TORT, NEGLIGENCE, OR OTHER THEORY OF LIABILITY ARISING OUT OF THE INSTALLATION OR USE OF OR INABILITY TO USE THE SOFTWARE, EVEN IF NOKIA OR ITS AFFILIATES ARE ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME COUNTRIES/STATES/JURISDICTIONS DO NOT ALLOW THE ABOVE EXCLUSION OR LIMITATION OF LIABILITY, BUT MAY ALLOW LIABILITY TO BE LIMITED, IN SUCH CASES, NOKIA, ITS EMPLOYEES' OR AFFILIATES' LIABILITY SHALL BE LIMITED TO U.S.\$50. Nothing contained in this disclaimer shall prejudice the statutory rights of any party dealing as a consumer.

Options in the memory card: [Backup phone mem.](#), [Restore from card](#), [Format mem. card](#), [Memory card name](#), [Set password](#), [Change password](#), [Remove password](#), [Unlock memory card](#), [Memory details](#), [Help](#), and [Exit](#).

Details of how you can use the memory card with other features and applications of your phone are given in the sections describing these features and applications.

Keep all memory cards out of the reach of small children.

Use only compatible Multimedia cards (MMC) with this device. Other memory cards, such as Secure Digital (SD) cards, do not fit in the MMC card slot and are not compatible with this device. Using an incompatible memory card may damage the memory card as well as the device, and data stored on the incompatible card may be corrupted.

Format memory card

When a memory card is formatted, all data on the card is permanently lost.

Some memory cards are supplied pre-formatted and others require formatting. Consult your retailer to find out if you must format the memory card before you can use it.

- Select **Options**→ [Format mem. card](#).

Select **Yes** to confirm. When formatting is complete, key a name for the memory card (max. 11 letters or numbers).

Backing up and restoring information

To back up information from your phone's memory to the memory card, select **Options**→ [Backup phone mem.](#)

To restore information from the memory card to the phone's memory, select **Options**→ [Restore from card](#).

You can only back up the phone memory and restore it to the same phone.

Locking the memory card

To set a password to lock your memory card against unauthorised use, select **Options**→[Set password](#).

You will be asked to enter and confirm your password. The password can be up to eight characters long.

The password is stored in your phone and you don't have to enter it again while you are using the memory card on the same phone. If you want to use the memory card on another phone, you will be asked for the password.

Unlocking a memory card

If you insert another password-protected memory card in your phone, you will be prompted to enter the password of the card. To unlock the card:

- Select **Options**→[Unlock memory card](#).

Once the password is removed, the memory card is unlocked and can be used on another phone without a password.

Checking memory consumption

You can check the memory consumption of different data groups and the available memory for installing new applications or software on your memory card:

- Select **Options**→[Memory details](#).

Services and Applications



Go to **Menu** → **Web**
or press and hold
 in standby
mode.

Web (Mobile browser)

Various service providers maintain pages specifically designed for mobile phones, offering services that can be, for example, news, weather reports, banking, travel information, entertainment, and games. With the mobile browser you can view these services as WAP pages written in WML, XHTML pages written in XHTML, or a mixture of both. If you have not yet used your phone to make a WAP connection, you may need to contact your service provider for assistance with the first-time connection or visit www.nokia.com/phonesettings.

A cache is a memory location that is used to store data temporarily. If you have tried to access or have accessed confidential information requiring passwords, empty the cache after each use. The information or services you have accessed is stored in the cache. To empty the cache, select **Options** → *Navigation options* → *Clear cache*.

Check the availability of services, pricing, and tariffs with your network operator and/or service provider. Service providers will also give you instructions on how to use their services.

Basic steps for accessing

- Save the settings that are needed to access the browser service that you want to use. [See "Setting up the phone for the browser service" on page 103.](#)
- Make a connection to the service. [See "Making a connection" on page 103.](#)
- Start browsing the web pages. [See "Browsing" on page 104.](#)
- End the connection to the service. [See "Ending a connection" on page 107.](#)

Setting up the phone for the browser service

Receiving settings in a smart message

You may receive service settings in a special text message, a so-called smart message, from the network operator or service provider that offers the service. [See "Receiving smart messages" on page 51.](#) For more information, contact your network operator or service provider.

Keying in the settings manually

Follow the instructions given to you by your service provider.

- 1 Go to *Settings*→*Connection*→*Access points* and define the settings for an access point. [See "Connection settings" on page 66.](#)
- 2 Go to *Web*→*Options*→*Bookmark manager*→*Add bookmark*. Write a name for the bookmark and the address of the browser page defined for the current access point.

Making a connection

Once you have stored all the required connection settings, you can access browser pages.

There are three different ways to access browser pages:

- Select the homepage () of your service provider.
- Select a bookmark from the Bookmarks view.
- Press the keys  -  to start to write the address of a browser service. The Go to field at the bottom of the display is immediately activated and you can continue writing the address there.

After you have selected a page or written the address, press  to start to download the page.

Options in the Bookmarks view (when a bookmark or folder is selected): *Open*, *Download*, *Back to page*, *Bookmark manager*, *Mark/Unmark*, *Navigation options*, *Advanced options*, *Send*, *Find bookmark*, *Details*, *Settings*, *Help*, and *Exit*.

Viewing bookmarks

Your device may have some bookmarks loaded for sites not affiliated with Nokia. Nokia does not warrant or endorse these sites. If you choose to access them, you should take the same precautions, for security or content, as you would with any Internet site.

In the Bookmarks view, you can see bookmarks pointing to different kinds of browser pages. Bookmarks are indicated by the following icons:



- The starting page defined for the browser access point. If you use another browser access point for browsing, the starting page is changed accordingly.



- The last visited page. When the phone is disconnected from the service, the address of the last visited page is kept in memory until a new page is visited during the next connection.

When you scroll through bookmarks, you can see the address of the highlighted bookmark in the Go to field at the bottom of the display.



- A bookmark showing the title.

Adding bookmarks manually

- 1 In the Bookmarks view, select **Options** → *Bookmark manager* → *Add bookmark*.
- 2 Start to fill in the fields. Only the address must be defined. The default access point is assigned to the bookmark if no other one is selected. Press  to enter special characters such as /, ., :, and @. Press  to clear characters.
- 3 Select **Options** → *Save* to save the bookmark.

Browsing

On a browser page, new links appear underlined in blue and previously visited links in purple. Images that act as links have a blue border around them.

Keys and commands used in browsing

- To open a link, press .
- To scroll the view, use the scroll key.
- To enter letters and numbers in a field, press the keys  - . Press  to enter special characters such as /, ,, :, and @. Press  to clear characters.
- To go to the previous page while browsing, press **Back**. If **Back** is not available, select **Options**→ *Navigation options*→ *History* to view a chronological list of the pages you have visited during a browsing session. The history list is cleared each time a session is closed.
- To check boxes and make selections, press .
- To retrieve the latest content from the server, select **Options**→ *Navigation options*→ *Reload*.
- To open a sublist of commands or actions for the currently open browser page, select **Options**→ *Service options*.
- Press and hold  to disconnect from a browser service and to quit browsing.

Saving bookmarks

- To save a bookmark while browsing, select **Options**→ *Save as bookmark*.
- To save a bookmark received in a smart message, open the message in the Inbox in Messaging and select **Options**→ *Save to bookmarks*. See "[Receiving smart messages](#)" on page 51.

Viewing saved pages

If you regularly browse pages containing information which doesn't change very often, you can save and then browse them when offline.

- To save a page, while browsing select **Options**→ *Advanced options*→ *Save page*.
- Saved pages are indicated by the following icon:



- The saved browser page.

In the saved pages view you can also create folders to store your saved browser pages. See Fig. 20, p. 106.

Options when browsing: *Open, Service options, Bookmarks, Save as bookmark, View image, Navigation options, Advanced options, Send bookmark, Find, Details, Settings, Help, and Exit*.

Options in the Saved pages view: *Open, Back to page, Reload, Saved pages mgr., Mark/Unmark, Navigation options, Advanced options, Details, Settings, Help, and Exit*.



Fig. 20 The Saved pages view.

Folders are indicated by the following icon:

 - Folder containing saved browser pages.

- To open the Saved pages view, press  in the Bookmarks view. In the Saved pages view, press  to open a saved page.

To start a connection to the browser service and to retrieve the page again, select **Options** → *Navigation options* → *Reload*.

The phone stays online after you reload the page.

Downloading

You can download items such as ringing tones, images, operator logos, software, and video clips through the mobile browser. These items can be provided free or you can purchase them.

Once downloaded, items are handled by the respective applications on your phone, for example, a downloaded photo will be saved in the Gallery.



Important: Only install applications from sources that offer adequate protection against harmful software.

A cache is a memory location that is used to store data temporarily. If you have tried to access or have accessed confidential information requiring passwords, empty the cache after each use. The information or services you have accessed is stored in the cache. To empty the cache, select **Options** → *Navigation options* → *Clear cache*.

Purchasing an item

To download the item:

- 1 Scroll to the link and select **Options** → *Open*.
- 2 Choose the appropriate option to purchase the item, for example, Buy.

Carefully read all the information provided.

If the online content is compatible, you can use your wallet information to make the purchase:

- 1 Select *Open wallet*. You will be prompted for your wallet code. [See "Entering the wallet code" on page 84.](#)
- 2 Select the appropriate card category from your wallet.
- 3 Select *Fill in*. This will upload the selected wallet information.

If the wallet does not contain all information necessary for the purchase, you will be requested to enter the remaining details manually.

Copyright protections may prevent some images, ringing tones, and other content from being copied, modified, transferred or forwarded.

Checking an item before downloading

You can see details about an item before you download it. Details about an item may include the price, a brief description and size. See Fig. 21, p. 107.

- Scroll to the link and select **Options**→ *Open*.
Details about the item are displayed on your phone.
- If you want to continue with the downloading, press *Accept*, or if you want to cancel the download, press *Cancel*.

Ending a connection

- Select **Options**→ *Advanced options*→ *Disconnect*, or
- Press and hold  to quit browsing and to return to standby mode.

Browser settings

Select **Options**→ *Settings*:



Fig. 21 Example of details in a content file.

- *Default access point* - If you want to change the default access point, press  to open a list of available access points. The current default access point is highlighted. [See "Connection settings" on page 66.](#)
- *Show images* - Choose if you want to view pictures when you are browsing. If you choose *No*, you can later load images during browsing by selecting **Options**→ *Show images*.
- *Text wrapping* - Choose *Off* if you don't want the text in a paragraph to automatically wrap, or *On* if you do. If text is not wrapped, the ends of lines may be truncated.
- *Font size* - You can choose five text sizes in the browser: *Smallest*, *Small*, *Normal*, *Large*, and *Largest*.
- *Default encoding* - To make sure your browser pages display text characters correctly, select the appropriate language type.
- *Cookies* - *Allow/Reject*. You can enable or disable the receiving and sending of cookies (a means of content providers to identify users and their preferences for frequently used content).
- *Security warnings* - Choose to hide or show security notifications.
- *Conf. DTMF sending* - *Always/First time only*. Choose whether you want to confirm before the phone sends DTMF tones during a voice call. [See "Options during a call" on page 17.](#) For example, you can make a voice call while you are viewing a browser page, send DTMF tones while a voice call is in progress, and save in Contacts a name and phone number from a browser page.
- *Wallet* - Choose *On* if you want the wallet to open automatically when a compatible browser page is opened.



Application manager

← Go to **Menu**→
Tools→ **App. manager**

In Application manager you can install new compatible Symbian operating system applications (SIS files) and Java™ applications (Java MIDlets and MIDlet suites). You can also update and uninstall applications from the phone, and monitor the installation history. See Fig. 22, p. 110.

Applications in Application manager use shared memory. [See "Shared memory" on page 14.](#)

When you open Application manager, you can see a list of:

- Applications saved in Application manager.
- Partially installed applications (indicated by .
- Fully installed applications that you can remove (indicated by .

You can only use Symbian operating system applications with a .SIS extension.

Your phone supports J2ME™ Java applications. Do not download PersonalJava™ applications to your phone as they cannot be installed.

Installing applications – general information

You can install applications that are specifically intended for this phone and suitable for the Symbian operating system.

If you install an application that is not intended specifically for this phone, it may function and look different from what was originally intended.

Applications may be downloaded to your phone during browsing, received as attachments in multimedia messages or e-mails, or received via Bluetooth from another device, for example, a phone or a compatible PC.



Important: Only install applications from sources that offer adequate protection against harmful software.

To increase protection, the application installation system uses digital signatures and certificates for applications. Do not install the application if Application manager gives a security warning during installation.

If you install an application that contains an update or repair to an existing application, you can only restore the original application if you have the original application or a full backup copy of the removed application. To restore the original application, first remove

Options in the Application manager main view: [Install](#), [View details](#), [View certificate](#), [Update](#), [Go to web address](#), [Remove](#), [View log](#), [Send log](#), [Settings](#), [App. downloads](#), [Help](#), and [Exit](#).



Fig. 22 The Application manager main view.

the updated or repaired application and then install again from the original application or the backup copy.

During installation, the phone checks the integrity of the application to be installed. The phone shows information about the checks being carried out and you are given options whether to continue or cancel the installation. Once the phone has checked the integrity of the application, it is installed on your phone.

Installing applications

- Open Application manager, scroll to the application, and select **Options**→ *Install* to start the installation.
- Alternatively, search the phone memory or the memory card, select the application, and press  to start the installation.

Some applications may give the option of partial installation allowing you to select the particular components of an application that you want to install. If you are installing an application without a digital signature or a certificate, the phone warns you of the risks. Continue installation only if you are absolutely sure of the origin and contents of the application

Installing Java™

The .JAR file is required for installation. If it is missing, the phone may ask you to download it. If there is no access point defined for Application manager, you will be asked to select one. When you are downloading the .JAR file, you may need to enter a user name and password to access the server. You obtain these from the supplier or manufacturer of the application.

- To start a data connection and to view extra information about the application, scroll to it and select **Options**→ *Go to web address*.
- To start a data connection and to check if there is an update available for the application, scroll to it and select **Options**→ *Update*.

Java settings

- To change the default access point that a Java application uses for downloading extra data, select **Options**→ *Settings*→ *Access point*. See "[Access points](#)" on page 66.
- To change the security settings that determine the actions that a Java application is permitted to do, select **Options**→ *Settings*.

Not all Java applications permit you to change the security settings.

Removing an application

- 1 To remove an application, scroll to it and select **Options**→ *Remove*.
- 2 Press **Yes** to confirm the removal.

If you remove an application, you can only re-install it if you have the original application or a full backup of the removed application. If you remove an application, you may no longer be able to open documents created with that application. If another application depends on the application that you removed, the other application may stop working. Refer to the documentation of the installed application for details.

Connectivity

Go to [Menu](#) →
[Connectivity](#) →
[Bluetooth](#)



Bluetooth connection

This device is compliant with Bluetooth Specification 1.1 supporting the following profiles: Dial-up networking profile (DUN) as a gateway, object push profile (OPP) as a client and server, File transfer profile (FTP) as a server, Hands-free profile (HFP) as an audio gateway, Generic object exchange profile (GOEP), Generic access profile (GAP), and serial port profile (SPP) with the PC connectivity software. To ensure interoperability between other devices supporting Bluetooth technology, use Nokia approved enhancements for this model. Check with the manufacturers of other devices to determine their compatibility with this device.

There may be restrictions on using Bluetooth technology in some locations. Check with your local authorities or service provider.

Features using Bluetooth technology, or allowing such features to run in the background while using other features, increase the demand on battery power and reduces the battery life.

Bluetooth technology enables wireless connections between electronic devices within a maximum range of 10 metres. A Bluetooth connection can be used to send images, videos, texts, business cards, calendar notes, or to connect wirelessly to compatible devices using Bluetooth technology, such as computers.

Since devices using Bluetooth technology communicate using radio waves, your phone and the other devices do not need to be in direct line-of-sight. The two devices only need to be within a maximum of 10 metres of each other, although the connection can be subject to interference from obstructions such as walls or from other electronic devices. Using Bluetooth technology consumes the battery and the phone's operating time will be reduced. Take this into account when performing other operations with your phone. There

may be restrictions on using devices using Bluetooth technology. Check with your local authorities.

When you activate Bluetooth for the first time, you are asked to give a name to your phone.

Bluetooth settings

- *Bluetooth* - On/Off.
- *My phone's visibility* - *Shown to all* - Your phone can be found by other Bluetooth devices or *Hidden* - Your phone cannot be found by other devices.
- *My phone's name* - Define a name for your phone.

After you have set Bluetooth as active and changed *My phone's visibility* to *All*, your phone and this name can be seen by other Bluetooth device users.

Sending data via Bluetooth

There can be only one active Bluetooth connection at a time.

- 1 Open an application where the item you wish to send is stored. For example, to send a photo to another device, open the Gallery application.
- 2 Scroll to the item you want to send and select **Options**→ *Send*→ *Via Bluetooth*.
- 3 The phone starts to search for devices within range. Devices using Bluetooth technology that are within range start to appear on the display one by one. You can see a device icon, the device's name, the device type, or a short name. Paired devices are shown with . A paired device is one where a Bluetooth connection already exists between your phone and the other device.
 - To interrupt the search, press **Stop**. The device list freezes and you can start to form a connection to one of the devices already found.

When searching for devices, some devices may show only the unique device addresses. To find out the unique address of your phone, enter the code ***#2820#** in standby mode. If you have searched for devices earlier, a list of the devices that were found previously is shown first. To start a new search, select *More devices*. If you switch off the phone,




Fig. 23 Using Bluetooth.



Fig. 24 Sending an image via Bluetooth, the phone starts to search for devices.

- the list of devices is cleared and the device search needs to be started again before sending data.
- 4 Scroll to the device you want to connect with and press **Select**. The item you are sending is copied to Outbox and the note *Connecting* is shown.
 - 5 Pairing (if not required by the other device, go to step 6.)
 - If the other device requires pairing before data can be transmitted, a tone sounds and you are asked to enter a passcode.
 - Create your own passcode (1-16 characters long, numeric) and agree with the owner of the other device to use the same code. This passcode is used only once and you do not have to memorise it.
 - After pairing, the device is saved to the Paired devices view.
 - 6 When the connection has been successfully established, the note *Sending data* is shown.
- Copyright protections may prevent some images, ringing tones, and other content from being copied, modified, transferred or forwarded.

Data received via Bluetooth can be found in the Inbox folder in Messaging. [See "Inbox - receiving messages" on page 50.](#)



Tip: Pairing means authentication. The users of the devices using Bluetooth technology should agree together what the passcode is, and use the same passcode for both devices in order to pair them. Devices that do not have a user interface have a preset passcode.

Icons for different devices:

- *Computer*, - *Phone*, - *Audio/video*, and - *Bluetooth device*.

If sending fails, the message or data will be deleted. The Drafts folder in Messaging does not store messages sent via Bluetooth.

Checking the status of the Bluetooth connection

- When is shown in standby mode, Bluetooth is active.
- When is blinking, your phone is trying to connect to the other device.

- When  is shown continuously, the Bluetooth connection is active.

Paired devices view

Paired devices are easier to recognise, they are indicated by  in the search result list. In the Bluetooth main view, press  to open a list of paired devices ().

- **To pair with a device:** Select **Options** → *New paired device*. The phone starts a device search. Scroll to the device you want to pair with and press **Select**. Exchange passcodes. The device is added to the Paired devices list.
- **To cancel pairing:** Scroll to the device whose pairing you want to cancel and press  or select **Options** → *Delete*. If you want to cancel all pairings, select **Options** → *Delete all*. If you are currently connected to a device, and delete the pairing with that device, the pairing is removed and the device connection is terminated, but Bluetooth remains active on the handset.
- **To set a device to be authorised or unauthorised:** Scroll to the device and select **Options** → *Set as authorised* - Connections between your phone and this device can be made without your knowledge. No separate acceptance or authorisation is needed. Use this status for your own devices, for example, your PC, or devices that belong to someone you trust. The icon  is added next to authorised devices in the Paired devices view. *Set as unauthorised* - Connection requests from this device need to be accepted separately every time.

Receiving data via Bluetooth

When you receive data via Bluetooth, a tone sound is played and you are asked if you want to accept the message. If you accept, the item is placed in the Inbox folder in Messaging. Messages received via Bluetooth are indicated by . [See "Inbox - receiving messages" on page 50.](#)

Disconnecting Bluetooth

A Bluetooth connection is disconnected automatically after sending or receiving data.



Connection manager

Go to [Menu](#) →
[Connectivity](#) →
[Connection manager](#)




Fig. 25 The Connection manager main view.

Options in the Connection manager main view when there are one or more connections: [Details](#), [Disconnect](#), [Disconnect all](#), [Help](#) and [Exit](#).

In Connection manager you can identify the status of multiple data connections, view details on the amount of data sent and received, and end unused connections. See Fig. 25, p. 116.

You can view details of data connections only. Voice calls are not listed.

When you open Connection manager, you can see a list of:

- Open data connections,  - [Data call](#),  - [GPRS](#)
- The status of each connection.
- Amount of data uploaded and downloaded for each connection (GPRS connections only).
- The duration of each connection (Data call connections only).



Note: The actual time invoiced for calls by your service provider may vary, depending on network features, rounding off for billing, and so forth.

Viewing connection details

To view the details of a connection, scroll to a connection and select [Options](#) → [Details](#). The following is displayed:

Name - The name of the Internet Access Point (IAP) in use.

Bearer - The type of data connection: [Data call](#) or [GPRS](#).

Status - The current status of the connection.

Received - The amount of data, in bytes, received to the phone.

Sent - The amount of data, in bytes, sent from the phone.

Duration - The length of time that the connection has been open.

Speed - The current speed of both sending and receiving data in kB/s (kilobytes per second).

Dial-up (GSM) - The dial-up number used, or *Name* (GPRS) - access point name used.

Shared (not displayed if the connection is not shared) - The number of applications using the same connection.

Ending connections

- Scroll to a connection and select **Options**→ *Disconnect* to end that connection only.
- Select **Options**→ *Disconnect all* to close all currently open connections.

Connecting your phone to a compatible computer

For further information on how to make a connection to a compatible computer via USB or Bluetooth, and how to install Nokia PC Suite 6.1, see the User's Guide for Nokia PC Suite on the CD-ROM. For further information on how to use Nokia PC Suite, see the help function on PC Suite or visit the support pages at www.nokia.com.

Sync - remote synchronisation

The Sync application enables you to synchronise your calendar or contacts with various calendar and address book applications on a compatible computer or on the Internet. Synchronisation takes place over a GSM data call or packet data connection.

 Go to **Menu**→
Connectivity→ **Sync**

Options in the Remote sync main view: [Synchronise](#), [New sync profile](#), [Edit sync profile](#), [Delete](#), [View log](#), [Help](#), and [Exit](#).

The synchronisation application uses SyncML technology for synchronisation. For information on SyncML compatibility, please contact the supplier of the calendar or address book application you want to synchronise your phone data with.

Creating a new synchronisation profile

- 1 If no profiles have been defined, the phone asks you if you want to create a new profile. Select **Yes**.
To create a new profile in addition to existing ones, select **Options** → [New sync profile](#). Choose whether you want to use the default setting values or copy the values from an existing profile to be used as the basis for the new profile.
- 2 Define the following:
 - [Sync profile name](#) - Write a descriptive name for the profile.
 - [Access point](#) - Select an access point you want to use for the data connection.
 - [Host address](#) - Contact your service provider or system administrator for the correct values.
 - [Port](#) - Contact your service provider or system administrator for the correct values.
 - [User name](#) - Your user ID for the synchronisation server. Contact your service provider or system administrator for your correct ID.
 - [Password](#) - Write your password. Contact your service provider or system administrator for the correct value.Press  to select:
 - [Calendar](#) - Select **Yes** if you want to synchronise your calendar.
 - [Remote calendar](#) - Enter a correct path to the remote calendar on the server. Must be defined if the previous setting [Calendar](#) has been set to **Yes**.
 - [Contacts](#) - Select **Yes** if you want to synchronise your contacts.
 - [Remote contacts](#) - Enter a correct path to the remote address book on the server. It must be defined if the previous setting [Contacts](#) has been set to **Yes**.
- 3 Press **Done** to save the settings.

Synchronising data

In the Sync main view, you can see the different profiles, and what kind of data will be synchronised: Calendar, Contacts, or both.

- 1 In the main view, scroll to a profile and select **Options**→ *Synchronise*. The status of the synchronisation is shown at the bottom of the screen.
To cancel synchronisation before it is finished, press **Cancel**.
- 2 You are notified when the synchronisation has been completed.
 - After synchronisation is complete, press **View log** or select **Options**→ *View log* to open a log file showing the synchronisation status (*Complete* or *Incomplete*) and how many calendar or contact entries have been added, updated, deleted, or discarded (not synchronised) in the phone or on the server.

Troubleshooting

Memory low

When the following notes are shown, the phone memory is low and you must start to delete some data: *Not enough memory to perform operation. Delete some data first.* or *Memory low. Delete some data.* To view what kind of data you have and how much memory the different data groups consume, go to [File manager](#) and select [Options](#)→[Memory details](#).

You may want to delete the following items regularly to avoid memory getting low:

- Messages from the Inbox, Drafts, and Sent folders in Messaging.
- Retrieved e-mail messages from the phone memory.
- Saved browser pages.
- Images and photos in Images.

If you want to delete contact information, calendar notes, call timers, call cost timers, game scores, or any other data, go to the respective application to remove the data.

If you are deleting multiple items and another of the following notes are shown: *Not enough memory to perform operation. Delete some data first.* or *Memory low. Delete some data.*, try deleting items one by one (starting from the smallest item).

Clearing calendar memory - To remove more than one event at a time, go to the Month view and select [Options](#)→[Delete entry](#)→ and either:

- [Before date](#) - to delete all calendar notes which take place before a certain date. Enter the date before which all calendar notes will be deleted.
- [All entries](#) - to delete all calendar notes.

Erasing log information - To erase all the log contents, Recent calls register, and Messaging delivery reports permanently, go to Logs and select [Options](#)→[Clear log](#) or go to [Settings](#)→[Log duration](#)→[No log](#).

Different ways to store data:

- Use Nokia PC Suite 6.1 to make a backup copy of all data to a compatible computer.
- Send images to your e-mail address and then save the images to your computer.
- Send data via Bluetooth to a compatible device.
- Store data on a compatible memory card.

Q&A

Phone display

- Q: Why do missing, discoloured or bright dots appear on the screen every time I turn on my phone?
A: This is a characteristic of this type of display. Some displays may contain pixels or dots that remain on or off. This is normal, not a fault.

Camera

- Q: Why do images look smudgy?
A: Check that the camera lens protection window is clean.

Bluetooth

- Q: Why can't I end a Bluetooth connection?
A: If another device is connected to your phone, you can either end the connection using the other device or by deactivating Bluetooth. Go to Bluetooth and select the setting *Bluetooth* → *Off*.
- Q: Why can't I find my friend's Bluetooth-enabled device?
A: Check that both have activated Bluetooth. Check that the distance between the two devices is not over 10 metres or that there are no walls or other obstructions between the devices. Check that the other device is not in 'Hidden' mode. Check that both devices are compatible.

Multimedia messaging

- Q: What should I do when the phone tells me that it cannot receive a multimedia message because memory is full?

A: The amount of memory needed is indicated in the error message: *Not enough memory to retrieve message. Delete some data first*. To view what kind of data you have and how much memory the different data groups consume, go to *File manager* and select *Options* → *Memory details*.

- Q: How can I end the data connection when the phone starts a data connection again and again? The notes: *Retrieving message* or *Trying to retrieve message again* are shown briefly. What is happening?

A: The phone is trying to retrieve a multimedia message from the multimedia messaging centre.

Check that the settings for multimedia messaging have been defined correctly and that there are no mistakes in phone numbers or addresses. Go to *Messaging* and select *Options* → *Settings* → *Multimedia message*.

To stop the phone from making a data connection, you have the following options. Go to *Messaging* and select *Options* → *Settings* → *Multimedia message*, and then:

- Select *On receiving msg.* → *Defer retrieval* if you want the multimedia messaging centre to save the message to be retrieved later, for example, after you have checked the settings. After this change, the phone still needs to send information notes to the network. To retrieve the message later, select *Retr. immediately*.
- Select *On receiving msg.* → *Reject message* - if you want to reject all incoming multimedia messages. After this change, the phone needs to send information notes to the network and the multimedia messaging centre will

delete all multimedia messages that are waiting to be sent to you.

- Select *Multimedia reception* → *Off* - if you want to ignore all incoming multimedia messages. After this change the phone will not make any network connections related to multimedia messaging.

Messaging

- Q: Why can't I select a contact?
A: If you cannot select a contact in the Contacts directory, the contact card does not have a phone number or an e-mail address. Add the missing information to the contact card in the Contacts application.

Calendar

- Q: Why are the week numbers missing?
A: If you have changed the Calendar settings so that the week starts on a day other than Monday, then the week numbers will not be shown.

Browser Services

- Q: *No valid access point defined. Define one in Services settings.*
A: Insert proper browser settings. Contact your service provider for instructions.

Log

- Q: Why does the log appear empty?

A: You may have activated a filter, and no communication events fitting that filter have been logged. To see all events, select **Options** → *Filter* → *All communication*.

PC connectivity

- Q: Why do I have problems in connecting the phone to my PC?
A: Make sure that Nokia PC Suite 6.1 is installed and running on your PC. See the User's Guide for Nokia PC Suite on the CD-ROM. For further information on how to use Nokia PC Suite, see the help function on PC Suite or visit the support pages at www.nokia.com.

Access codes

- Q: What is my password for the lock, PIN, or PUK codes?
A: The default lock code is **12345**. If you forget or lose the lock code, contact your phone dealer.
If you forget or lose a PIN or PUK code, or if you have not received such a code, contact your network service provider.
For information about passwords, contact your access point provider, for example, a commercial Internet Service Provider (ISP), service provider, or network operator.

Application not responding

- Q: How do I close an application that is not responding?
A: Open the application switching window by pressing and holding . Then scroll to the application, and press  to close the application.

Battery information

Charging and Discharging

Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times but it will eventually wear out. When the talk and standby times are noticeably shorter than normal, buy a new battery. Use only Nokia approved batteries, and recharge your battery only with Nokia approved chargers designated for this device.

Unplug the charger from the electrical plug and the device when not in use. Do not leave the battery connected to a charger. Overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time. Temperature extremes can affect the ability of your battery to charge.

Use the battery only for its intended purpose. Never use any charger or battery that is damaged.

Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object such as a coin, clip, or pen causes direct connection of the positive (+) and negative (-) terminals of the battery. (These look like metal strips on the battery.) This might happen, for example, when you carry a spare battery in your pocket or purse. Short-circuiting the terminals may damage the battery or the connecting object.

Leaving the battery in hot or cold places, such as in a closed car in summer or winter conditions, will reduce the capacity and lifetime of the battery. Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

Do not dispose of batteries in a fire! Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

Care and Maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

- Keep the device dry. Precipitation, humidity and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, remove the battery and allow the device to dry completely before replacing it.
 - Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
 - Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
 - Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
 - Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
 - Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
 - Do not paint the device. Paint can clog the moving parts and prevent proper operation.
 - Use a soft, clean, dry cloth to clean any lenses (such as camera, proximity sensor, and light sensor lenses).
 - Use only the supplied or an approved replacement antenna. Unauthorised antennas, modifications, or attachments could damage the device and may violate regulations governing radio devices.

All of the above suggestions apply equally to your device, battery, charger, or any enhancement. If any device is not working properly, take it to the nearest authorized service facility for service.

Additional safety information

A few practical rules about accessories and enhancements

- Keep all accessories and enhancements out of the reach of small children.
- When you disconnect the power cord of any accessory or enhancement, grasp and pull the plug, not the cord.
- Check regularly that enhancements installed in a vehicle are mounted and are operating properly.
- Installation of any complex car enhancements must be made by qualified personnel only.

Operating environment

Remember to follow any special regulations in force in any area and always switch off your device when its use is prohibited or when it may cause interference or danger. Use the device only in its normal operating positions. To maintain compliance with radio frequency exposure guidelines only use enhancements approved by Nokia for use with this device. When the device is on and being worn on the body, always use an approved holder or carrying case.

Parts of the device are magnetic. Metallic materials may be attracted to the device, and persons with a hearing aid should not hold the device to the ear with the hearing aid. Always secure the device in its holder, because metallic materials may be attracted by the earpiece. Do not place credit cards or other

magnetic storage media near the device, because information stored on them may be erased.

Medical devices

Operation of any radio transmitting equipment, including wireless phones, may interfere with the functionality of inadequately protected medical devices. Consult a physician or the manufacturer of the medical device to determine if they are adequately shielded from external RF energy or if you have any questions. Switch off your device in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Pacemakers Pacemaker manufacturers recommend that a minimum separation of 6 in. (15.3 cm) be maintained between a wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research. Persons with pacemakers should:

- always keep the device more than 6 in. (15.3 cm) from their pacemaker when the device is switched on;
- not carry the device in a breast pocket; and
- hold the device to the ear opposite the pacemaker to minimise the potential for interference.

If you have any reason to suspect that interference is taking place, switch off your device immediately.

Hearing aids Some digital wireless devices may interfere with some hearing aids. If interference occurs, consult your service provider.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection systems, electronic antiskid (antilock) braking systems, electronic speed control systems, air bag systems. For more information, check with the manufacturer or its representative of your vehicle or any equipment that has been added.

Only qualified personnel should service the device, or install the device in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty that may apply to the device. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or enhancements. For vehicles equipped with an air bag, remember that air bags inflate with great force. Do not place objects, including installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Using your device while flying in aircraft is prohibited. Switch off your device before boarding an aircraft. The use of wireless teledevices in an aircraft may be dangerous to the operation of the aircraft, disrupt the wireless telephone network, and may be illegal.

Potentially explosive environments

Switch off your device when in any area with a potentially explosive atmosphere and obey all signs and instructions. Potentially explosive atmospheres include areas where you would normally be advised to turn off your vehicle engine. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Switch off the device at refuelling points such as near gas pumps at service stations. Observe restrictions on the use of radio equipment in fuel depots, storage, and distribution areas, chemical plants or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), and areas where the air contains chemicals or particles such as grain, dust or metal powders.

Emergency calls



Important: Wireless phones, including this device, operate using radio signals, wireless networks, landline networks, and user-programmed functions. Because of this, connections in all conditions cannot be guaranteed. You should never rely solely on any wireless device for essential communications like medical emergencies.

To make an emergency call:

- 1 If the device is not on, switch it on. Check for adequate signal strength.
Some networks may require that a valid SIM card is properly inserted in the device.

- 2 Press  as many times as needed to clear the display and ready the device for calls.
- 3 Key in the official emergency number for your present location. Emergency numbers vary by location.
- 4 Press the  key.

If certain features are in use, you may first need to turn those features off before you can make an emergency call. Consult this guide or your service provider for more information.

When making an emergency call, give all the necessary information as accurately as possible. Your wireless device may be the only means of communication at the scene of an accident. Do not end the call until given permission to do so.

Certification information (SAR)

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed and manufactured not to exceed the limits for exposure to radio frequency (RF) recommended by international guidelines (ICNIRP). These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines were developed by independent scientific organisations through periodic and thorough evaluation of scientific studies. The guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for mobile devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit stated in the international guidelines is 2.0 W/kg*. Tests for SAR are conducted using standard operating

positions with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station, the lower the power output of the device.

The highest SAR value for this device when tested for use at the ear is 0.54 W/kg.

This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 2.2 cm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 2.2 cm away from your body.

In order to transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

* The SAR limit for mobile devices used by the public is 2.0 watts/kilogram (W/kg) averaged over ten grams of body tissue. The guidelines incorporate a substantial margin of safety to give additional protection for the public and to account for any variations in measurements. SAR values may vary depending on national reporting requirements and the network band. For SAR information in other regions please look under product information at www.nokia.com.

Index

A

Access points

Settings 66

Alarm clock

Snooze 90

Animations 36

Applications

Installing 110

Removing files 111

Automatic answer 71

B

Background images 41

Bluetooth 112

Closing the connection 116

Connection requests 114

Connection status indicators 114

Device icons 114

Pairing 114

Pairing requests 114

Passcode, glossary explanation
114

Preset passcode 114

Receiving data 115

Sending data 113

Unique device address 113

Browser

Connecting 103

Ending connections 107

Icons 104

Service messages 52, 53

WAP pages 102

XHTML pages 102

Browsing 104

C

Call register

See *Log*

Calls

Answering 17

Conference calls 16

Dialled 20

Diverting 17

Duration 20

International 15

Missed 20

Options during a call 17

Received 20

Rejecting 17

Settings 65

Transferring 18

Cell broadcast messages 56

Cell info display 71

Certificates

Trust settings 74

Chat

Sending messages 94

Clearing memory

Log information 120

Closed chat group 97

Computer connections 117

Conference calls 16

Connecting to a PC 117

Connection

Viewing 116

Connection indicators

Bluetooth 114

Contact cards

Removing ringing tones 23

Contact groups 25

Contacts

Data Import 32

Copying

Contacts between the SIM card and
phone memory 23

Text 48

Creating

Contact cards 22

D

Data connections to network

Ending 117

Viewing 116

Data Import
 Contacts 32
 Dialed numbers 20
 Digital rights management 106
 Diverting calls 17

E

E-mail
 Deleting 54
 Retrieving from mailbox 53

Erasing
 Recent calls register 20

F

Favourites
 Adding a shortcut 82

File formats
 RealOne Player 37
 SIS file 109

File manager 75

Folders
 Creating 13
 Organising 13

G

Gallery
 Picture messages 42
 Uploading images 42

GIF animations 36

GPRS
 See *Packet data*

GPRS connections 116

GSM data connections 116

I

Image server 42
 Importing data from other Nokia phones
 32

Indicators 10
 Info service 56
 Installing applications 110
 Installing Java files 110

J

Java
 Installing Java applications 110
 See *Applications*.

L

Language
 for writing 63

Listening to messages 16

M

Media files
 File formats 37
 Mute 38
 Seek 38

Media gallery 40
 Background images 41

Memory
 Viewing memory details 76

Memory low
 Viewing memory consumption 101

Menu 11

Menu key 11
 Missed calls 20
 Mobile browser 102
 Music files
 See *Media files*

Mute 38

N

Nickname in chat 93

P

Packet data
 Connection timer 21
 Data counter 21
 Settings 69

Pairing, glossary explanation 114

Password
 Memory card 101

PC Suite 117
 Personalisation 80
 Personalise 80
 Alarm 91

Phonebook
 See *Contacts*

Picture messages 41, 42
 Pictures 41, 42
 PIN code
 Unlocking 71

Predictive text input
 Tips 47
 Turning off 48

Profiles 79

Adding voice commands 77

Renaming 80

R**Received calls** 20**Receiving**

Data via Bluetooth 115

Ringing tones, Operator logos, and settings, see *Smart messages***Recent calls register**

Call duration 20

Dialled numbers 20

Erasing call lists 20

Missed calls 20

Received calls 20

Recorder, recording sounds 91**Recording video** 35**Rejecting calls** 17**Removing an application** 111**Removing software** 111**Ringing tones**

Muting 17

Receiving in a smart message 52

S**Screen saver**

Settings 64

Seek 38**Sending**

Data via Bluetooth 113

Service command editor 57**Shared memory** 14**Shortcuts**

in Favourites 82

SIM card

Copying names and numbers 23

SIS file 109**Smart messages**

Receiving 51

Snooze 90**Software**

Removing 111

Transferring a .SIS file to your phone 109

Sound clips 41**Sound files**See *Media files***Sounds**

Removing a personal ringing tone 23

Standby mode

Indicators 10

Settings 64

Stopping

Alarm clock 90

Switching between applications 12**Synchronisation**See *Remote synchronisation*.**T****Transferring calls** 18**U****Uploading images** 42**USSD commands** 57**V****Video clips** 41See *Media files***Video player**See *RealOne Player***Video recorder**

Memory card 35

Saving video clips 35

Settings 35

Viewing

Connection details 116

GIF animations 36

Network data connection details 116

Voice commands 76**Voice mailbox** 16

Changing the number 16

Voice messages 16**Voice recorder** 91**Voice tags**

Making calls 24

Volume control 13

W

WAP pages

Browser 102

Writing

Predictive text input, turning off 48

X

XHTML pages

Browser 102