



ECO-DECLARATION FOR NOKIA AC-4

Product type: Charger

Materials

The charger does not contain¹:

- Azo colorants and pigments with carcinogenic amino compounds
- Asbestos
- Benzene
- Beryllium Oxide
- Chlorofluorocarbons CFCs/HCFCs/Halons as banned in the Montreal Protocol
- Polychlorinated Biphenyls (PCB) or Polychlorinated Terphenyls (PCT)
- Short Chained Chlorinated Paraffins
- Endangered species of flora and fauna

Versions of this charger that are sold in China comply with the China legislation “Management Methods on the Prevention and Control of Pollution caused by Electronic Information Products” commonly known as “China RoHS”.



This charger does not contain the following substances in concentrations higher than allowed in the EU RoHS Directive 2002/95/EC:

- | | |
|----------------------------|---|
| • Cadmium | • Mercury |
| • Chromium VI ⁺ | • Polybrominated Biphenyls (PBB) or |
| • Lead | • Polybrominated Diphenyl Ethers (PBDE) |

¹ In levels more than 100 ppm by weight in the charger

All information in this eco-declaration is based on scientific analysis and/or data provided by suppliers. There may be some variance in the information.

Further material information

Antimony trioxide, Brominated and Chlorinated flame retardants are not added in the covers.

The surface parts of this device may contain a small amount of nickel. Persons who are sensitized to nickel may have symptoms from prolonged skin contact with these parts.

Polyvinylchloride (PVC) is not used in this charger or charger packaging material.



Energy consumption

The charger no-load energy consumption describes the amount of energy that is consumed when the charger is unplugged from the mobile device but still drawing on the mains:

No-load energy consumption: < 300 mW

This charger meets the Energy Star requirements (Ver 1.1).





Recycling and disassembly

Charger has been marked according to WEEE directive requirement for recycling. Do not dispose of your charger as unsorted municipal waste.

INSTRUCTIONS FOR THE USER

- Always unplug the charger from the wall socket after the device is fully charged. This avoids unnecessary power consumption of the charger in standby and saves energy.
- Electronic devices shall not be thrown into household waste but be separated for correct recycling.
- For environmentally sound recycling, contact your local Nokia service point or check local regulations for correct disposal of household electronics.
- Please separate the packaging material according to responsible waste disposal options and sorting for recycling.
- See the **Recycling Map** on <http://www.nokia.com/environment> to find the nearest collection point for used mobile phones and accessories.