



Product type: Audio Enhancement

Weight: 11g

## **Materials**

The product does not contain<sup>1</sup>:

- Azo colorants and pigments with carcinogenic amino compounds
- Asbestos
- Benzene
- Beryllium Oxide
- Chlorofluorocarbons CFCs/HCFCs/Halons as banned in the Montreal Protocol
- Polychlorinated Biphenyls (PCB) or Polychlorinated Terphenyls (PCT)
- Short Chained Chlorinated Paraffins
- Endangered species of flora and fauna

Versions of this product that are sold in China comply with the China legislation "Management Methods on the Prevention and Control of Pollution caused by Electronic Information Products" commonly known as "China RoHS".



The product does not contain the following substances in concentrations higher than allowed in the EU RoHS Directive 2002/95/EC:

- Cadmium
- Chromium VI+
- Lead

- Mercury
- Polybrominated Biphenyls (PBB) or
- Polybrominated Diphenyl Ethers (PBDE)

<sup>&</sup>lt;sup>1</sup> In levels more than 100 ppm by weight in the product

All information in this eco-declaration is based on scientific analysis and/or data provided by suppliers. There may be some variance in the information.



## **Further material information**

Antimony trioxide, Brominated and Chlorinated flame retardants are not added in the covers.

**ECO-DECLARATION** 

The surfaces that are intended for direct and prolonged skin contact do not release nickel (Ni) above levels specified in (94/27/EEC).

Polyvinylchloride (PVC) is not used in this product or product packaging material.



## Recycling and disassembly

All mechanical plastic parts have been marked where practically possible<sup>2</sup>. Plastic parts are marked in accordance with ISO 11469 and ISO 1043-1 to -4 standards.

Product has been marked according to WEEE directive requirement for recycling. Do not dispose of your product as unsorted municipal waste.

Product contains a built-in Li-ion Polymer battery.

All information in this eco-declaration is based on scientific analysis and/or data provided by suppliers. There may be some variance in the information.

<sup>&</sup>lt;sup>2</sup> Dependant on size, location and materials of the part

3(3)



## INSTRUCTIONS FOR THE USER

Always unplug the charger from the wall socket after the device is fully charged. This avoids unnecessary power consumption of the charger in standby and saves energy.

**ECO-DECLARATION** 

- Electronic devices shall not be thrown into household waste but be separated for correct recycling.
- For environmentally sound recycling, contact your local Nokia service point or check local regulations for correct disposal of household electronics.
- Please separate the packaging material according to responsible waste disposal options and sorting for recycling.
- See the Recycling Map on http://www.nokia.com/environment to find the nearest collection point for used mobile phones and accessories.